SERVICE NOTES


PROGRAMMABLE SYNTHESIZER


First Edition

TABLE OF CONTENTS/目次	Page
SPECIFICATIONS	仕様
PANEL	パネル・・・・・・・・・・・2
EXPLODED VIEW	分解図3—5
DISASSEMBLY / ASSEMBLY	分解組立手順 · · · · · · 6
KEYBOARD	鍵盤6—8
IDENTYFING VERSION NUMBER	バージョン番号の確認方法 ・・・・・・・・・・9
RESTORING THE FACTORY PRESETS	ファクトリー・プリセットの設定方法9
ADJUSTMENT	調整 9
DATA SAVE AND LOAD	データのセーブ/ロードの方法 ・・・・・・・9
CIRCUIT DISCRIPTION	回路解説10—13
PARTS LIST	パーツリスト 14, 15
BLOCK DIAGRAM	ブロック図 ・・・・・・・・・・・ 16
CIRCUIT BOARD (MAIN)	基板図(メイン)・・・・・・17
CIRCUIT DIAGRAM (MAIN)	回路図 (メイン)
CIRCUIT BOARDS (VOLUME_L and ENCODER)	基板図(ボリューム L,エンコーダ) · · · · · · 20
CIRCUIT DIAGRAM (ENCODER)	回路図(エンコーダ)・・・・・・20
CIRCUIT DIAGRAM (VOLUME_L)	回路図(ボリューム L)・・・・・・・・・・21
CIRCUIT BOARD (VOLUME_R)	基板図(ボリューム R)・・・・・・・・22
CIRCUIT DIAGRAM (VOLUME_R)	回路図(ボリューム R)・・・・・・・23
CIRCUIT BOARD (JACK)	基板図(ジャック) 24
CIRCUIT DIAGRAM (JACK)	回路図(ジャック)・・・・・・・・25
CIRCUIT BOARDS	基板図
(SWITCH_A,B,C,CARD,LED and BENDER)	(スイッチ A,B,C,カード,LED,ベンダー) · · · · · 26
CIRCUIT DIAGRAMS	回路図
(SWITCH_A,B,C,CARD,LED and BENDER)	(スイッチA,B,C,カード,LED,ベンダー)・・・・・27, 28
CIRCUIT BOARD	基板図
(POWER SUPPLY, JUMPER, PROMARY)	(電源、ジャンパー、プライマリ) ‥‥‥‥ 29
TEST MODE	テストモード・・・・・・・・・・3032
TROUBLSHOOTING	トラブルシューティング ・・・・・・・・・・・・・・・・・ 33―41
IC DATA	ICデータ ······ 41 — 43

SPECIFICATIONS/仕様

● Keyboard ·······:: Weighted-action 61keys	● Weight: 15.0 kg	
(with velocity and channel aftertouch)	33.1 lbs	
● Maximum polyphony···: 24 voices	● MIDI channel: 1 - 16ch	
Parts·····:: Part 1 to 5,Special part	● Card slots······:: DATA card × 1	
Memories · · · · : Internal (INT) :	WAVEFORM card × 1	
System setup 1	● Inputs: HOLD PEDAL	
Patch 64	EXT CONTROLL	
Special setup 1	MIDI IN	
DATA card (CARD):	Outputs·····::MIX OUT L/R	
System setup 1	DIRECT OUT L/R	
Patch 64	MIDI OUT/THRU	
Special setup 1	PHONES	
● Internal waves:: 108	● Power consumption…: 25W (100V,120V),30W (230V,240V)	
• Effects·····:: Single mode:	● Accessories ······: △ AC cord (detachable)	
3 band EQ,	100V : DC-320-J01	13439825
Distortion, Phaser, Spectrum, Enhancer	117V : 120V UC 704-J01	13439812F0
Chorus, Delay, Reverb,	230V : 220V DNS EC210-J06	13439813F0
Mix out filter	240VA : 240V 3P SC415-J06	13439814F0
Multi mode:	240VE : UK BB6742-BB6791	23495110
3 band EQ,	Owner's Manual set	
Reverb, Chorus + Reverb, Delay + Reverb,	English :	26045448
Mix out filter	Japanese :	26045447
● Displays ·····:: LCD: 22 characters,2 lines (backlight)	Connection cable (PJ-1M)	23430675S0
16 characters,2 lines (backlight)	● Options · · · · · : M - 256E Data card	
LED: 8 segments,2 characters	SL-JD800-xx JD-800 Sound Library	
● Dimensions ·····:: (W) 1040 × (D) 424 × (H) 118 mm		
(W) 40-15/16" × (D) 16-11/16" × (H) 4-10/16"		





1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 PANEL/パネル

※2 Stereo slide VR (10kB).

Part Name	Part Number	1	2	3	4	5	6	7	8	9	10	11	12	13
B KNOB S	22485253	0	0	0	0	0	0	0	0	0	0	0	0	
B KNOB CS	22485252								-					0
B POT ESCUTCHEON 1P	22225358										0	0		
B POT ESCUTCHEON 2P	22225359							0	0	0				
B POT ESCUTCHEON 3P	22225360				0	0	0							
B POT ESCUTCHEON 4P	22225361	0	0	0										
B KNOB HOLDER 1P	22205540										0	0	0	
B KNOB HOLDER 2P	22205541							0	0	0				
B KNOB HOLDER 3P	22205542				0	0	0							
B KNOB HOLDER 4P	22205543	0	0	0										
EWA-NPE × 05B15	13339481	0	0		0	0		0	0		0			
EWA-NPK × A3B15 **1	13339483		0	0		0	0		0	0		0		
EWA-NAO × 05B14	13359366												0	
RK11K113	13289133													0

EWA-NPE × 05B15 EWA-NAO × 05B14	
※1 With center click, EWA-NPK × A3B15	

Part Name	Part Number	14	15	16	17	18	19	20	21	22	23	24
B KEYTOP A 1P	22495251	0										
B KEYTOP A 2P	22495252		0									
B KEYTOP A 3P	22495253			0								
B KEYTOP A 4P	22495254				0							
B KEYTOP AD 1P	22495255					0				-		
B KEYTOP AD 2P	22495256						0					
B KEYTOP B	22495258							0				
B KEYTOP C	22495259								0			
B BUTTON	22495603									0		
LED GL3HS8	15029259					0	0				0	0
LED SPACER LDS-120R	12169370		-			0	0					
LED HOLDER 2P	22205533										0	
LED HOLDER 4P	22205534											0
SKPDAC 250G	13169727	0	0	0	0	0	0					
SKHVBD 100G	13169697							0	0			
EVQ-Q8R13K	13169728									0		

	FALETIC ON	
Roland JD-800 PAGGRAMMABLE SYNTHESIZER	TO THE STREET THE STRE	
VOLUME SYSTEM PATCH TRACTOR O O O O O O O O O O O O O O O O O O		

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 EXPLODED VIEW / 分解図

	No.	- PARTS NAME -	- PARTS No
	1	Volume_L Board·····	····· 7626618001
	2	VolumeR Board ·····	····· 7626631001
	3	Encoder Board······	··· (7626618001)
Ŀ	4	Switch A Board ······	····· 7626634001
1	5	Bender Board ······	··· (7626637001)
	6	Switch B Board	··· (7626637001)
	7	LED Board ······	··· (7626637001)
	8	LCD Display LM40 × 212 ·······	15029523
	9	Display Cover ······	22045265
	10	Switch C Board	····· 7626637001
	11	B Knob CM·····	22485251
	12	B Knob CS·····	22485252
	13	Bender Unit PB-A0106 ··········	23275929
	45	Leaf Terminal ······	
	47	SW_A Preparing Lead	23485879
	48	Coaching Clip CS-4	
:	49	Panel Holder ·····	22205561

- SCREW -

B 3 × 8mm B.Tight Binding Fe.Cm C 3 × 8mm P.Tight Pan Head Fe.BC B

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 EXPLODED VIEW/分解図

8.			
	No.	- PARTS NAME -	- PARTS No
	14	Lower Panel R	·······21125499
	15	Side Holder R	22205536
	16	LCD Holder·····	22205539
à.	17	Side Panel Holder B	22205563
9	18	Side Holder L	22205535
	19	Lower Panel L	······ 21125498
	20	Side Panel Holder A	22205562
	21	Side Panel L	21125496
	22	Side Panel R·····	21125497
	23	Front Panel B	2225440
	24	Front Panel A	22225439


- SCREW -


48 Coaching Clip CS-4

A 3 × 6mm P.Tight Pan Head Fe.BC


B 3 × 8mm B.Tight Binding Fe.Cm

C 3×8 mm P.Tight Pan Head Fe.BC






DISASSEMBLY / ASSEMBLY / 分解組立手順




KEYBOARD/鍵盤

JD-800 (SK-761-E) PARTS LIST

NO.	PARTS NO.	PARTS NAME	
	22575254W0	SK-7 NATURAL KEY C/F	257-254
l [22575256W0	₩ E/B	257-256
[22575258W0	<i>II</i> D	257-258
1	22575259W0	и G	257-259
[22575253W0	JJ A	257-253
	22575255W0	# C' ∕F'	257-255
2	22575261W0	SK-7 SHARP KEY	257-261
3	22815653	SK-7 CHASSIS 61P	281-653 - SK-761-E CHASSIS
4	22155775	SK-7 GUIDE BUSH	215-775 ASSY 22815677
5	22265504	SK-7 FELT B 61KEY	226-504
	22185236A	SK-7 CONTACT RUBBER 12PW	218-236A - SK-761 CONTACT RUBBER
6	22185237A	SK-7 CONTACT RUBBER 13PW	218-237A 7621422000A
7	7626621000A	SK-761-E CONTACT BOARD AS	SSY
8	22205309	SK-761 CONNECTOR HOLDER	220-309
9	22935121	CONNECTORBOARD ASSY A	
10	23475345	FUJI CARD 26X420-A6. 0 BBF	R-P1. 25
11	23165730	AFTERTOUCH 61P ASSY-A	
12	22175203	SK-7 SPRING W	217-203
12	22135435	STOPPER 12P	213-435
1.3	22135436	STOPPER 13P	213-436
14	* * * * * * *	TAPPING SCREWS 3X8 B1	*
15	* * * * * * *	NYLON RIVET NRP-355	x






[KEY REMOVAL]

1. Remove the stopper.

【KEYの取りはずし方】


1. ストッパーをはずします。



2. Pulling the key in the direction of arrow 2, disengage the key fulcrum from the chassis. See Fig.3 and Fig.4 for disengage status.


2. KEYを手前(方向2)に引き、KEY支点部をシャーシ係合部から 離します。

Fig.3、Fig.4は、離された状態です。



3. Taking care not to distort the spring, lift the key in the direction of 3.

3. KEY を引き上げます。(方向3) この時スプリングを変形させない様、注意してください。




[KEY INSTALLATION]

1. Place the spring onto the chassis as show in Fig.6.


【KEYの取り付け方】

1. Fig.6 に示す様、スプリングをシャーシに置きます。



2. Referring to Fig.8, press the key in the direction of 4.

2. スプリングをKEYスプリング係止部にあて (Fig.8参照)、方向4




CAUTION : _


Firmly rest the spring on the spring dent (Fig.8). Don't let the spring stop at the slope D or the key touch will differ from previous sensitivity.

注意: -スプリングをFig.8に示すスプリング係止部に確実に係止しな いと(斜面Dに止まる事がある) KEY タッチが変化します。

3. Verify that there is on clearance between the key fulcrum and portion E in the chassis. Attach the stopper (Fig.10) on the portion F.

3. KEY 支点部とシャーシ係合部間(E)に隙間の無い事を確認し、ス トッパーをシャーシ裏側に、Fig.10に示す(F)に沿ってシャーシ と鍵の隙間に押し込む様にして貼ります。





7

[CONTACT BOARD INSTALLATION]

First align the ϕ 2.1mm hole between C3 and c#3 of the contact board with a half pierce of the chassis. Next align the slot (ϕ 2.1 × 4mm) of remaining octaves with half pierces, respectively. Make sure the joint of the CIC cable and the board end are on the left end of the lowest G of the chassis. The CIC cable cannot be detached as it is thermally sealed to the contact board.

【基板の取り付け方】

まず $C3 \ge C # 3$ キーの中間にある $\phi 2.1$ mmの基板の丸穴をシャーシのハーフピアスに合わせ、次に1 オクターブに1 コずつある $\phi 2.1 \times 4$ mmの長穴を合わせて行きます。

この時、CICケーブルと基板のつなぎ目がシャーシ低音部左端(G)と一致する事を確認してください。なお、CICケーブルと基板は、熱圧着されている為、分離できません。




Fig.11

[CONTACT RUBBER SHEET INSTALLATION]

Place the contact rubber sheet on the contact board. Align contact projections with holes in the board. Press the hole in top face of the projection with a small rod (like clip shown in Fig.12) so that the projection is held in a hole of the chassis. Note that the left end of a rubber contact should be placed over the right end of the left side rubber sheet (see H in Fig.12).

【接点ゴムの取り付け方】

接点ゴムの足を基板の穴に合わせて置き、先端のとがっていない細い棒状の物で接点ゴム上面の穴を押さえシャーシに係止します。治具としてクリップを図の様に伸ばした物を使用すると良いでしょう。また、接点ゴムの左端は、その左側の接点ゴム右端に重ねる様係止します。(H部参照)




Fig.12

CAUTION:


When removing a contact rubber sheet, gently pull it off the baord or sheet will break off. 接点ゴムを取りはずす時、無理に引っ張るとゴム足が切れることがあるので慎重に扱ってください。

[INSTALLING THE AFTERTOUCH CIC TO THE CONNECTOR BOARD]

Fasten screws from the backside using the holes (1), at the D1 key chassis shank section on the connector board.

【コネクターボードへのアフタータッチ、 CIC の取り付け方】

コネクターボードは、シヤーシD1KEY軸部付近にある穴(1)を使用して裏側からビスで固定します。



A lock is provided on the CIC cable connector. The lock releases when both sides of the connector are gripped and pulled out in the direction of (2). The lock attaches when pushed in the direction of (3). Lock the CIC cable in position after plugging it in and release the lock before removing the cable.

Plug the AFTER TOUCH and the FUJI CARD directly into the connector. (Plug in to lock.) In order to remove, simply pull. (The lock will release when the right amount of force is exerted while pulling).

After plugging the FUJI CARD into the connector, seal it to the chassis with double-sided tape. (FUJI CARD bends in a right angle at the A # 2 KEY position)

CICケーブル用のコネクターにはロックがついています。コネクターの両端を持って(2)方向に引くとロックが解除され、(3)方向に押すとロックされます。CIC取り付けの際には、、CICケーブルを差し込んだ後にロックを行い、取り外す前にロックの解除を行って下さい。

アフタータッチ及びフジカードは、コネクターにそのまま差し込んで下さい。(差し込むとロックされる。)

はずす時は、そのまま引き抜いて下さい。(ある程度、引く抜き方向 に負荷がかかるとロックが解除される。)

フジカードはコネクターに差し込んだ後、シャーシに貼付てある両面テープで固定します。(A # 2KEYの位置でフジカードを直角に折り曲げます。)

IDENTIFYING VERSION NUMBER

- 1. Press the [MULTI] button to set the JD-800 in Multimode.
- 2. Press the [EXIT] button while simultaneously pressing both the [CURSOR L] and [CURSOR R] buttons.
- (the same method used for entering Test Mode)
- 3. The version number is displayed on the screen at the right.

バージョン番号の確認方法

- 1. [MULTI] ボタンを押し、JD-800をマルチモードにします。
- 2. [CURSOR L] と [CURSOR R] を同時に押しながら、[EXIT] ボタンを押します。
- (テストモードの入り方と同じです。)
- 3. 右画面にバージョン番号が表示されます。

Test mode select EXIT + B/N Roland JD-800 ver 1.00 XXXX

> VERSION NUMBER バージョン番号

RESTORING THE FACTORY **PRESETS**

- · The original factory settings will be restored to the entire memory space when performing the following operation. Make sure to transfer user data to a DATA card (M-256E) before executing this operation. (Refer to "Data Save and Load" page 9.)
- 1. Turn on the power.
- 2. After pressing the [DATA TRANSFER] button, press the [PAGE ▲] button six times to call up the "Factory preset" screen.

3. Complete the procedure by pressing the [INC/YES] button.

ファクトリー・プリセットの 設定方法

- ・以下の操作を行うと、メモリーはすべて工場出荷時の設定に書き 変わります。ユーザーのデータが入っている場合は、必ずデータ をDATAカード (M-256E) に移しておいて下さい。(データの セーブ/ロードの方法 (P.9) を参照して下さい。)
- 1. 電源を入れます。
- 2. [DATA TRANSFER] ボタンを押した後、[PAGE ▲] ボタンを 6回押して、"Factory preset"の画面を呼び出して下さい。

Factory preset

[Y/N]

3. [INC/YES] ボタンを押すと完了です。

.

ADJUSTMENT

[1] Adjusting D/A Conversion

- · Use VR1 on the jack board for adjustment.
- · See [15] D/A Adjustment, in the TEST MODE section, page 32, for details.

[2] Adjusting LCD Contrast

- · Use VR1 on the main board for adjustment.
- The display becomes dark when turning the VR1 toward the right, and becomes light when turning it toward the left.

調整

【1】D/A調整

- ・調整はジャックボード上の VR1 によって行います。
- ・詳細はテストモードの「【15】 D/A 調整」(P.32) を参照して下 さい。

【2】LCDコントラスト調整

- ・ 調整はメインボード上の VR1 によって行います。
- ・ VR1 を右へ回すと表示が濃くなり、左へ回すと薄くなります。

DATA SAVE AND LOAD

· Save and Load by using the DATA card.

【1】セーブの方法

します。

1. DATAカードをDATAスロットへ確実に差し込み、DATAカー ドのプロテクトをoffにします。

データのセーブ/ロードの方法

・DATAカードを使用してセーブ/ロードを行なう方法を下記に示

2. [DATA TRANSFER] ボタンを押した後、「PAGE ▲ ▼] を押し て、"INT→CRD"の画面を呼び出します。

DATA TRANS INT + CRD *ALL Patch Setup [Y/N]

-
- 3. Select the data to be saved by moving [▶] mark by using the [CURSOR ◀▶].

1. Insert the DATA card into the DATA slot, and turn off

2. After pressing the [DATA TRANSFER] button, press

[PAGE ▲▼] to read out the "INT → CRD" screen.

the memory protect function of the DATA card.

4. Press [INC/YES].

[1] Saving

- *The display below will appear if a non-initialized DATA card is inserted.
- 3. [CURSOR **◄▶**] を押して [▶] マークを動かし、セーブするデー タを選びます。
- 4. [INC/YES] を押します。
- ※この時、イニシャライズされていないDATAカードが挿入されて いると、以下の表示が出ます。

Wron9 DATA card overwright sure?[Y/N]

This message means "Do you wish to overwrite all data on the DATA card with that from internal memory?" All internal data (ALL) are automatically transferred when pressing [INC/YES].

Data can be read from and written to the DATA card without initialization when the above operation is completed.

この画面は「本体のメモリー・エリアの全てのデータをDATAカー ドに重ね書きしてもよいですか?」ということを表しています。 ここで [INC/YES] を押すと、自動的に本体の全てのデータ (ALL) が転送されます。

以上の操作を行うと、イニシャライズの操作をしなくてもDATA カードに読み書きできるようになります。

[2] Loading

- 1.Insert the DATA card into the DATA slot.
- 2. After pressing the [DATA TRANSFER] button, press [PAGE $\blacktriangle \blacktriangledown$] to call up the "CRD \rightarrow INT" screen.

【2】ロードの方法

- 1. DATAカードをDATAスロットに挿入します。
- 2. [DATA TRANSFER] ボタンを押した後、[PAGE ▲ ▼] を押し て、"CRD→INT"の画面を呼び出します。

DATA TRANS CRD+INT ▶ALL Patch Setup [Y/N]



- 3. Select the data to be loaded by moving the [▶] mark by using the [CURSOR ◀▶].
- 4. Press [INC/YES].
- *The data in the internal memory area will be written over when this operation is executed. If you have some important data in the internal memory, make sure to save them to another card beforehand.
- 3. [CURSOR **◄▶**] を押して [▶] マークを動かし、ロードするデー タを選びます。
- 4.[INC/YES] を押します。
- ※この操作を実行すると、本体のメモリー・エリアのデータが書き 変わってしまいます。大事なデータが本体のメモリーに残ってい る場合、あらかじめ他のカードにセーブして保存しておいて下 さい。

CIRCUIT DISCRIPTION

[OUTLINE]

The CPU for the JD-800 system is IC36 (on the Main Board. abbreviated as "MB"). IC21—IC24 (on MB) are for the sound sources, IC5 (on MB) is for the panel operation interface, IC11 (on MB) is for the keyboard interface, and IC28 (on MB) is for the memory card interface.

[POWER SOURCE SECTION]

- · By IC2 (on the Power Supply Board, hereafter abbreviated as "PB") a stable power supply of +5V is provided for the digital power supply. By IC3 and IC4 (on the PB) a stable power supply of $\pm 15V$ is provided for the analog power supply. The rating of the +5V power supply is 1A, and that of the \pm 15V source is 500mA.
- · Reset signal are sent by IC1 (on the PB). IC1 keeps the reset to Low level approximately for 300msec after the +5V power supply is started. This delay time is decided by C7 (on the PB).
- · IC1 also monitors the +5V power souce, and when the voltage reaches a point lower than + 4.25V, it sets the reset to Low level. (See Fig.1.)

回路解説


【概説】

JD-800はIC36 (on the Main Board、略記MB) をCPUとする システムです。IC21~IC24 (on MB) は音源部、IC5 (on MB) は パネル操作系インターフェース、IC11 (on MB) はキーボードイン ターフェース、IC28 (on MB) はメモリーカードのインターフェー スです。

【雷源部】

- ・ IC2 (on Power Supply Board、略記PB) によって安定化され た+5Vがデジタル系の電源として供給されています。また。IC3 及びIC4 (on PB) によって安定化された±15Vがアナログ系の 電源として供給されています。+5V電源の定格は1A、±15V電 源の定格は500mAです。
- ・IC1 (on PB) によってリセット信号が作られています。IC1は+ 5V電源が立ち上がった後、およそ300mSの間リセットをLow レ ベルに保ちます。この遅延時間はC7 (on PB) によって決定され

また、IC1 は+5V電源を監視し、電圧が+4.25V以下に下がると リセットをLow レベルにします。(Fig.1)



 $D = 0.34 \times C7 (pF)$ usec.

Fig.1

・LEDの点灯用電源として、Unreg.+5Vを、またミュート回路用

・電源はCN1、CN2及びCN3 (on PB) からシステムへ供給されて

います。CN1 はジャックボード (略記JB) に接続され、CN2及び

CN3 はメインボードに接続されています。CN2 と CN3 はメイン

圧はおよそ+10V、Unreg.+15Vはおよそ+22Vです。

ボードにおいては別系統の電源です。

としてUnreg. + 15Vを使用しています。Unreg. + 5Vの実際の電

- Unregulated power of +5V is used for lighting the LEDs and unregulated power of +15V is used for the mute circuit. The actual voltage of the unregulated +5V is about + 10V and that of unregulated + 15V is about + 22V.
- . The power is supplied to the system from CN1, CN2 and CN3 (on the PB). CN1 is connected to the Jack Board (abbreviated as "JB") and CN2 and CN3 are connected to the MAIN Board. CN2 and CN3 are independent power supplies on the MAIN Board.

· The output adresses from IC36 (on MB) are decoded by

IC13 (on MB), and then become chip select signals for

each IC. IC13 also transfers the interruptions from each

[CPU PERIPHERALS]

IC altogether to IC36. (See Fig.2.)

【CPU 周辺】

・ IC36 (on MB) から出力されたアドレスはIC13 (on MB) でデ コードされ、各ICへのチップセレクト信号となります。IC13はま た各ICからの割り込みを一括してIC36に転送します。(Fig.2)




Fig.2

- · A 20MHz clock pulse is supplied to IC36. IC36 turns the pulse into a system clock signal by dividing. The system clock signal is divided and supplied also to IC5, IC11 and IC13 (on the MB).
- · When the power is turned on, IC36 reads in the battery voltage for memory backup from the analog input port. It also reads in the battery voltage in the Card when a DATA Card is inserted. In both cases, an error message is displayed when the voltage reaches a point less than + 2.7V or more than + 3.5V.
- · IC36 sends and receives MIDI from the serial port.

[MEMORY]

- · IC31 (on the MB) is a 2-Mb ROM chip with the system program written in.
- · IC29 and IC30 (on the MB) are RAM circuits. The data memorized to IC29 is backed up even after the power is turned off, and it includes data related to the sound programs, including patches and special setups, etc. IC30 is a RAM circuit for working data and temporary memory storage, etc.
- · The DATA card is used to save sound program data. The DATA card is interfaced by IC28.

About the backup circuit:

When the reset signal is switched to the Low level. IC29 is set to the standby condition, and at the same time Vcc is cut off from the +5V power supply by Q7 and Q8 (on the MB), activating the back-up condition.(See Fig.3.)


- ・ IC36 には20MHzのクロックが供給されています。IC36 はこれを 2分周してシステム・クロックとしています。システム・クロック はIC5、IC11及びIC13 (on MB) にも分配して供給されています。
- IC36は電源投入時にアナログ入力ポートからメモリーバックアッ プ用バッテリーの電圧を読み込みます。また、DATAカード挿入 時にカード内のバッテリー電圧を読み込みます。いずれの場合 も、電圧値が+2.7V以下もしくは+3.5V以上の場合にエラーメッ セージを表示します。
- ・ IC36 はシリアルポートより MIDI の送・受信を行います。

【メモリー】

- ・IC31 (on MB) は2MbitのROMで、システムプログラムが書き 込まれています。
- ・ IC29及びIC30 (on MB) はRAMです。IC29はバッテリーによっ て電源を切った後も内容がバックアップされており、パッチ、ス ペシャルセットアップ等、音色に関するデータが記憶されます。 また、IC30はワーキング用のRAMであり、テンポラリー・エリ ア等がここに割り当てられています。
- ・ 音色データの保存に DATA カードを使用できます。 DATA カー ドはIC28によってインターフェースされています。


バックアップ回路について:

リセット信号がLow レベルになると、IC29 はスタンバイ状 態になり、同時にQ7及びQ8 (on MB) の働きによってVcc が + 5V 電源から切り離されてバックアップ状態になりま す。(Fig.3)



[PANEL OPERATION AND CONTROLLER]

- The LCD display is controlled by IC13 (on the MB). The contrast of LCD is adjusted by VR1. The best contrast can be gained when the voltage on VR1 is about 0.5 to 0.6V.
- The power supplied to the LCD's back light is limited by Q5 and Q6 (on the MB), to avoid an excess of electricity.
- The Bender, Modulation, After Touch, EXT. Pedal and all panel operations, except that of the LCD, are read in by IC5 (on the MB).
- The slider outputs a voltage within a range of 0 to +5V according to the position of the control. The outputs of eight sliders are input to one 4051. After being multiplexed by the multiplexing signals from IC5 (on the MB), they are input through the analog input port of IC5 passing through the voltage follower. The outline of the ciruit is shown in Fig.4 and the multiplexing signals from IC5 is shown in Fig.5.




The A/D converter of IC5 converts the input analog voltage, and when the value is changed, it interrupts IC36 (on the MB).

 The rotary encoder outputs two phased pulses whose phases are staggered every single click rotation. (See Fig. 6 (a), (b).)


【パネル操作系及びコントローラ】

- ・LCDの表示はIC13 (on MB) によって行われています。また、LCDのコントラストはVR1によって調整されます。VR1 にかかる電圧がおよそ $0.5\sim0.6$ Vの時に、最も良好なコントラストが得られます。
- ・LCDのバックライトに供給される電流はQ5及びQ6 (on MB) によって制限され、過大な電流が流れないようになっています。
- LCD以外のパネル操作系とベンダー、モジュレーション、アフタータッチ及びEXT.PedalはIC5 (on MB) によって読み込まれています。
- ・スライダーはつまみの位置に応じた電圧を $0\sim+5$ Vの範囲で出力します。8本分のスライダー出力は1個の4051に入力され、IC5(on MB)からのマルチプレクス化信号によってマルチプレクスされた後、ボルテージ・フォロワを通ってIC5のアナログ入力ポートに入力されます。回路の概略をFig.4に、また、IC5からのマルチプレクス化信号をFig.5に示します。




IC5 は入力されたアナログ電圧をA/D変換し、値に変化があった場合にはIC36(on MB)に対して割り込みをかけます。

・ロータリー・エンコーダーは1クリック回転させるごとに、位相の ずれた2相のパルスを出力します。(Fig.6 (a)、(b))



The waves of these pulses are reformed by the filter, which consists of RA7, C6, and C7 (on the MB), and the schmidt trigger IC6 (on the MB), from which they are input to the IRQ0 of IC5 and port 8.(See Fig.7)

このパルスはRA7、C6及びC7 (on MB) によって構成されるフィルターと、シュミット・トリガーIC6 (on MB) によって波形整形された後、IC5のIRQ0とポート8に入力されます。(Fig.7)



IC5 reads in port 8 at the trailing edge of IRQ0, then judges the direction of the rotation.

Twenty-four clicks per one rotation is used for the rotary encoder.

IC5 はIRQ0の立ち下がりエッジでポート8を読み込み、回転方向を 判断します。

なお、ロータリー・エンコーダーは1回転当り24クリックのものを 使用しています。

- The switch consists of an 8×8 matrix, and it is scanned by port 2 of IC5. Scanning pulse is active during Low, and it is also shares use with the scanning for dynamic lighting of the LEDs. Switch data is read in from port 6. (See Fig.8, Fig.9.)
- ・スイッチは 8×8 のマトリクスに構成され、IC5のポート2によってスキャンされています。スキャンニング・パルスはアクティブLowであり、LEDのダイナミック点灯用スキャンと兼用になっています。スイッチ・データはポート6から読み込まれます。(Fig. 8、Fig.9)





Fig.8



The sense circuit of the WAVEFORM card is included in the switch matrix. (Fig. 10.)

スイッチ・マトリクスにはWAVEFORMカードのセンス回路が含まれています (Fig.10)。





Fig.10

When the WAVEFORM card is inserted and CARDSENS reaches the High level, the action of the gate effectively accomplishes the same thing as the switch being pressed down.

- The LED consists of an 8 × 8 matrix just like the switch, and dynamic lighting is accomplished. The matrix is scanned by port 2 of IC5 and data for lighting are output from port 1. The LEDs are lit up by the power flow of the driver IC2 and IC3 (on the MB). (See Fig. 8.)
- The Bender unit is a type of rheostat and output voltage is taken from the moveable terminals. Voltage of + 5V is on the positive terminal and polarity voltage through Q4 (on the MB) by IC5 is on the negative terminal. The fixed terminal of resistance mid point is connected to the ground. The output of the bender is multiplexed by IC4 (on the MB), then read in by IC5.(See Fig.11.)

WAVEFORM カードが挿入されて CARDSENS が High レベルになると、ゲートの働きによって、スイッチが押されたのと同様の状態になります。


- ・LEDはスイッチと同様、 8×8 のマトリクス状に構成され、ダイナミック点灯が行われています。マトリクスはIC5のポート2によってスキャンが行われ、ポート1からは点灯用データが出力されます。LEDはドライバーIC2及びIC3 (on MB) の電流出力で点灯します。(Fig.8)
- ・ベンダー・ユニットは一種の可変抵抗器であり、可動端子から出力が取り出されます。+端子には+5V電圧がかけられ、-端子にはIC5よりQ4 (on MB) を通じてPolarity電圧が加えられます。また、抵抗体中点の固定端子はGNDに接続されています。ベンダーの出力はIC4 (on MB) でマルチプレクスされ、IC5に読み込まれます。(Fig.11)



IC5 sets the polarity voltage to +5V at first in order to read the bender, then it sets the polarity voltage to 0V, and re-reads the bender. The polarity is judged by the value which is read the second time.

IC5 は、まず Polarity 電圧を + 5V にしてベンダーを読み込み、次に Polarity 電圧を 0V にして再びベンダーを読み込みます。極性は 2 度目に読み込んだ値によって判定されます。

- Modulation and after touch is the pressure resistance, and the change of the resistance value by pressure are converted into 0—+5V voltage change, and then input into IC4. IC4 multiplexes the signal, then inputs it to IC5. Resistance values-voltage conversion circuit is shown in Fig.12.
- ・モジュレーション及びアフタータッチは感圧抵抗であり、圧力による抵抗値の変化が $0\sim+5$ Vの電圧変化に変換されてIC4に入力されます。IC4はこれらをマルチプレクスしてIC5に入力します。 抵抗値-電圧変換回路を Fig.12 に示します。




[KEYBOARD]

- The keyboard has 61 keys, and each key has two contact points, "make" (MK) and "break" (BR). Velocity values are determined based on the time difference of MK on and BR on.
- A total of 122 contact points consist on an 8×16 matrix. They are scanned by T0—T7 of IC11 (on the MB). IC11 interrupts IC36 when reading the keyboard.
- The key matrix is shown in Fig.13 and the timing of the scanning pulse is shown in Fig.14.

【鍵盤部】

- ・鍵盤は61個のkeyを持ち、個々のkeyはメーク (MK) とブレーク (BR) のの2つの接点を持っています。MK onとBR onの時間差をもとにしてベロシティ値が決定されます。
- ・これら、合計 122 個の接点は 8×16 のマトリクス状に構成され、 IC11 (on MB) の $T0 \sim T7$ によってスキャンされています。IC11 は鍵盤を読み込むと IC36 に対して割り込みをかけます。 キーマトリクスを Fig.13 に、また、スキャンニング・パルスのタイミングを Fig.14 に示します。



T0
T1
T2
T3
T4
T5
T6
T7
211usec

Fig.14

- IC11 also reads in the HOLD Pedal. The circuit is shown in Fig.15.
- ・IC11はHOLD Pedalの読み込みも行っています。回路をFig.15に示します。





Fig.15

[SOUND SOURCE]

- PCM data is memorized in IC25, IC26 (on the MB), and IC1 (on the Card Board). This memory and the PCM data read from the WAVEFORM Card are processed by IC21—IC24 (on the MB), and are output as serial data. IC22 functions for the TVF. IC21 executes the effect processing.
- Serial data is converted from digital to analog by IC11 (on the JB), then is demultiplexed by IC13 (on the JB) before becoming voice waveforms.
- The signals for muting of the output are made from the reset signals. The circuit is shown in Fig.16. The interval, from which the reset signal reaches High until the mute is released, is determined depending on the capacity of C68. The mute signals continue to output by D6 and C67 for a while after the power is turned off.

【音源部】

- ・IC25、IC26 (on MB) 及びIC1 (on Card Board) にはPCMデータが記憶されています。これらのメモリーまたはWAVEFOROMカードから読み出されたPCMデータはIC21~IC24 (on MB) において処理され、シリアルデータとして出力されます。IC22 はTVFです。また、IC21 はエフェクト処理を行います。
- ・ シリアルデータはIC11 (on JB) でD/A変換された後、IC13 (on JB) によってデマルチプレクスされて音声波形となります。
- ・Output のミュート用の信号はリセット信号から作られています。 回路をFig.16に示します。C68の容量によって、リセット信号が Highになってからミュートが解除するまでのインターバルが決定 されます。また、D6とC67によって、電源 off 後もしばらくの間 ミュート信号が出力され続けます。



PA	RTS LIST/	/パー	ツリ	スト		
				• • •		
SAFET	TY PRECAUTIONS:	CONSIDE	RATIONS O	N PARTS ORDERING	3	
,	, , , , , , , , , , , , , , , , , , , ,					wing items in the order sheet.
•	ne parts marked A have Nety-related characteristics.	, which older	QTY	PART NUMBER	DESCRIPTION	
•	se only listed parts for	Ex.	10	22485251	B KNOB CM (Rota	
6	placement.	3	15	13169697	SKHVBD100G (tact	,
					correct number and des	ription will result in delayed or
安全上的	の注意:		vered replace			
	が付いている部品は、安全	2	主に関するお			
. –	特別な規格でつくられたも	オーダーシー			こ記入して下さい。(例外	
	です。 }	(FI)	<u>必要数</u> 10	<u>パーツナンバー</u> 22485251	<u>品名</u> B KNOB CM (Rot	<u>使用機種</u> ary) JD-800
	換の際は、指定された部品	3	15	13169697	SKHVBD100G (tact	
2 -	号以外の部品は使わないよ	₹ もし記入漏れ	1、誤記等が7	する場合、必要部品が	発送できなかったり、大	當な遅れの原因になります。
う	にして下さい。	御協力をお願	願いします。			
·	~~~~~~~~~~					
ASING	ケース					
22225439	FRONT PANEL A					
22225440	FRONT PANEL B					
21125498	LOWER PANEL L					
21125499	LOWER PANEL R					
21125496	SIDE PANEL L					
21125497	SIDE PANEL R					
22815778	BOTTOM CHASSIS			for	CN14 on MB	
22225365	CARD ESCUTCHEON CARD ESCUTCHEON				CN14 on MB	
22225367 22225358	B POT ESCUTCHEON IP			101	CIVI OII CD	
22225359	B POT ESCUTCHEON 1P					
22225360	B POT ESCUTCHEON 3P					
22225361	B POT ESCUTCHEON 4P					
12359139	FF-018 Black	Ru	bber Foot			
22045265	DISPLAY COVER					
22325168	HINGE				*	
HASSIS	シャーシ					
22205561	PANEL HOLDER					
22205562	SIDE PANEL HOLDER A					
22205563	SIDE PANEL HOLDER B SIDE HOLDER L					
22205535	SIDE HOLDER L					

		ON PARTS ORDERING Is listed in the parts list PART NUMBER 22485251	G I, please specify the following ite DESCRIPTION B KNOB CM (Rotary)	ams in the order sheet. MODEL NUMBER JD-800	When returning a	PCB that cannot be	nen repair is impossible. >> repaired, first pack the PCB casheet (see below) and always in		
	15	13169697	SKHVBD100G (tact SW)	JD-800	≪修理不可能で基板を返却	する場合の注意点≫			ł
ındeli	ompletely fill vered replac 主に関するお	ement.	correct number and description t	will result in delayed or			(詳細は下記参照) を明記して、 <u>必ず</u> <u>ਹして返却するようにして下さい。</u>	対象の返却基版に添えて返	
ーシ- 例)	ートには、必 <u>必要数</u> 10 15	ず下記の4項目は正確 <u>パーツナンバー</u> 22485251 13169697	に記入して下さい。(例外は除く) <u>品名</u> B KNOB CM (Rotary) SKHVBD100G (tact SW)	使用機種 JD-800 JD-800	Necessary Informatio 必要事項	en			
	れ、誤記等が 買いします。	有る場合、必要部品が	発送できなかったり、大幅な遅れ	の原因になります。	1.Company Name サービス名	2.Model 機種名	3. Serial Number 製造番号	4.Symptom 症状	}
					*********				-

MB	\Rightarrow	Main Board	JUB	\Rightarrow	Jumper Board
JB	⇔	Jack Board	SAB	⇔	SWA Board
VLB	\Rightarrow	Volume_L Board	SCB	\Rightarrow	SW_C Board
EB	\Rightarrow	Encoder Board	SBB	⇔	SW_B Board
VRB	\Rightarrow	Volume_R Board	BB	⇔	Bender Board
PSB	\Rightarrow	Power Supply Board	LB	\Rightarrow	LED Board
PB	\Rightarrow	Primary Board	СВ	\Rightarrow	Card Board

CASING	ケース		* * * * * * * * * * * * * * * * * * * *
22225439	FRONT PANEL A		
22225440	FRONT PANEL B		
21125498	LOWER PANEL L		
21125499	LOWER PANEL R		
21125496	SIDE PANEL L		
21125497	SIDE PANEL R		
22815778	BOTTOM CHASSIS		
22225365	CARD ESCUTCHEON		for CN14 on MB
	CARD ESCUTCHEON		for CN1 on CB
22225367			for Civi on CD
22225358	B POT ESCUTCHEON 1P		
22225359	B POT ESCUTCHEON 2P		
22225360	B POT ESCUTCHEON 3P		
22225361	B POT ESCUTCHEON 4P		
12359139	FF-018 Black	Rubber Foot	
22045265	DISPLAY COVER		
22325168	HINGE		
	2		
CHASSIS	シャーシ		· · · · · · · · · · · · · · · · · · ·
22205561	PANEL HOLDER		
22205562	SIDE PANEL HOLDER A		
22205563	SIDE PANEL HOLDER B		•
22205535	SIDE HOLDER L		
22205536	SIDE HOLDER R		
22205538	JACK HOLDER		On JB
22205539	LCD HOLDER		
22205537	TRANS HOLDER		
23455322	LEAF TERMINAL		
23400322	LEAT TERMINAL		
KNOB, BUTTO	N ツマミ、ボタン		
22485251	B KNOB CM	248-251	WG WAVE FORM
20-100201	(Rotary)		
22485252	B KNOB CS	248-252	PITCH COARSE, PITCH FINE
20300232		240 202	THOI COMOS, ITION PINS
00.405050	(Rotary)	040, 050	DALETTE TONE A /D /C /D
22485253	B KNOB S	248-253	PALETTE TONE A/B/C/D,
	(Slider)		LFO 1/2 RATE/DELAY/FADE,
			PITCH RANDOM, WG/TVF KEY FOLLOW,
			AFTER MOD, WG LF01/LF02, LEVER,
			CUT OFF FREQUENCY, RESO,
			TVF ENV, TVF/TVA AFTER,
			TVF/TVA LFO, TVA LEVEL,
			BIAS POINT, BIAS LEVEL,
			PITCH/TVF/TVA ENV VELO,
			PITCH/TVF/TVA ENV TIME VELO,
			PITCH/TVF/TVA ENV TKF,
			PITCH ENV LO/T1/L1/T2/T3/L2,
			TVF ENV T1/L1/T2/L2/T3/SUS LEV/T4/L4,
			TVA ENV T1/L1/T2/L2/T3/SUS LEV/T4/L4,
		`	VALUE, VOLUME
22495251	B KEYTOP A 1P	249-251	EXIT, INT/CARD, LAYER/ACTIVE
	B KEYTOP A 2P	249-252	TUNE/FUNC, MIDI, PART L/R,
22495252	B RETTOF A 2F	245-202	
			EDIT COMMON, EDIT EFFECTS,
			WRITE, DATA TRANSFFER
22495253	B KEYTOP A 3P	249-253	PART EDIT, SPECIAL SET UP,
			MULTI EFFECTS, COMPARE,
			COPY, MANUAL
22495254	B KEYTOP A 4P	249-254	BANK1-8, NUMBER1-8
22495255	B KEYTOP AD 1P	249-255	KEY TRANSPOSE
22495256	B KEYTOP AD 2P	249 - 256	SINGLE, MULTI,
25430500	Z ILLI IOI IID EI	D-10 D00	TONE A, TONE B,
			TONE C, TONE D, SOLO, PORTAMENTO
			LOW I WINTEN I O
22495258	в кеутор в	249-258	PAGE U/D, CURSOR L/R
22495259	B KEYTOP C	249-259	INC. DEC
22495603	B BUTTON	249-603	HOLD CONTROLL, VELOCITY CURVE,
			LFO 1/2 WAVE FORM,
			LFO 1/2 OFFSET,
			LFO 1/2 KEY TRIG,
			WG AFTER BEND, WG BENDER,
			WAVE SOURCE, TVF MODE,
			TVF/TVA LFO SELECT,
			TVA BIAS DIRECTION
SWITCH	スイッチ		
△13149108	WK2A44 6A/250V/		Power Switch
13169728	EVQ-Q8R13K	(light touch)	SW1-SW12 on VLB
10100100	_ : 4 401.1011	(10001)	SW1-SW4 on VRB
13169697	SKHVBD100G	(tact switch)	
19198081	SVUADDIOOG	(Idel SWITCH)	SW2 and SW3 on SBB
			SW9 and SW17-SW19 on SCB
13169727	SKPDAC 250G	(heavy touch)	SW1-SW16 on SAB
			SW1 on SBB
			SW1-SW8, SW10-SW16 and SW20-SW26 on SCB
			SW1-SW3 on BB
			SWI SWO ON DD
			SWI SWO ON DB


	ジャック、ソケット				
13449145	YKB21-5010	PHONES		JK1 on JB	
	(stereo)	EXT CONT		JK6 on JB	
13449146	YKB21-5012	MIX OUT L/R.		JK2-JK5 and JK7 on JB	
	(mono)	DIRECT OUT L/R			
		PEDAL HOLD			
13429273	YKF51-5046	MIDI IN/OUT/THE	(U	JK8 on JB	
10400551	(triple)	22n IC socket		Program ROM IC31,	
13429551	DICF-32CS-E	32p IC socket		PCM ROM-A IC25 and	
				PCM ROM-B IC26 on MI	1
				PCM ROM-C IC1 on CB	,
				TOWN TOWN C TOT ON CD	
DISPLAY UNIT	ディスプレイ・ユニット				
15029523	LM40 × 212	LCD Display		2 lines of 40 characters	
10020000	NOTE: Replacement should	be made on a unit bassis.			
	No replacements av	railable for individual parts.			
	注 : 交換は、ユニット単位	でおこなって下さい。			
	補修用部品はユニット	単位で供給されます。			
15029365	GL6S220	8 Seg LED		LED1 on LED Board	
BENDER UNIT	ベンダー・ユニット				
23275929	PB- A0106	327-929			
		be made on a unit bassis.			
		railable for individual parts.			
	注 : 交換は、ユニット単位				
	補修用部品はユニット	単位で供給されます。			
1/51/00 ADD	鍵盤完成品				
KEYBOARD					
7626620000	SK-761-E	TO LIGT (D.O.) (
	Note: See KEYBOARD PAR		٠		
	注 :詳細はキーホード・パー	-ツ・リスト (P.6) を参照して下	51,0		
PCB ASSY	基板完成品			-	
E 7626690000	Main Board	(pcb 22925990)			
	Jack Board	(pcb 22925991)			
7626618001	Volume L Board	(pcb 22925992)			
1020010001	Note: Volume_L Board incl	•			
		Encoder Boardが含まれます。			
7626631001	Volume_R Board	(pcb 22925993)			
	Power Supply Board	(pcb 22925994)			
				D d	
	Note: Power Supply Board	includes Primary Board and	Jumper	Board.	
		includes Primary Board and 。 にはPrimary Board及びJumpe			
7626634001					
7626634001 7626637001	注:Power Supply Board Switch A Board Switch C Board	にはPrimary Board及びJumpe (pcb 22925995) (pcb 22925996)	r Board	が含まれます。	
	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include:	にはPrimary Board及びJumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board	r Board	が含まれます。 ED Board.	
	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board にはSW	にはPrimary Board及びJumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board _B Board, Bender Board及び	r Board	が含まれます。 ED Board.	
	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include:	にはPrimary Board及びJumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board	r Board	が含まれます。 ED Board.	
7626637001 7626608000	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board にはSW Card Board	にはPrimary Board及びJumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board _B Board, Bender Board及び	r Board	が含まれます。 ED Board.	
7626637001 7626608000 IC 集積回	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board にはSW Card Board	にはPrimary Board 及び Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board _B Board, Bender Board 及び (pcb 22925996)	r Board	が含まれます。 ED Board. oardが含まれます。	
7626637001 7626608000 IC 集積回 15209315	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board にはSW Card Board	にはPrimary Board 及び Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board _B Board, Bender Board 及 (pcb 22925996)	r Board	が含まれます。 ED Board. oard が含まれます。 IC31 on MB	· · · · · · · · · · · · · · · · · · ·
7626637001 7626608000 IC 集積回 15209315 15209290	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board にはSW Card Board Mask ROM 2Mbit MB838000-20P-G-2A6	にはPrimary Board 及び Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board (pcb 22925996) Program ROM PCM ROM-A	r Board	が含まれます。 ED Board. oardが含まれます。 IC31 on MB IC25 on MB	· · · · · · · · · · · · · · · · · · ·
7626637001 7626608000 IC 集積回 15209315 15209290 15209291	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board にはSW Card Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A7	にはPrimary Board 及び Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board _B Board, Bender Board 及び (pcb 22925996) Program ROM PCM ROM-A PCM ROM-B	r Board	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC26 on MB	
7626637001 7626608000 IC 集積回 15209315 15209290 15209291 15209305	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board にはSW Card Board Mask ROM 2Mbit MBB38000-20P-G-2A6 MBB38000-20P-G-2A7 MB838000-20P-G-2A8	にはPrimary Board 及び Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board _B Board, Bender Board 及 (pcb 22925996) Program ROM PCM ROM-A PCM ROM-B PCM ROM-C	r Board	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB	· · · · · · · · · · · · · · · · · · ·
7626637001 7626608000 IC 集積回 15209315 15209290 15209291	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board にはSW Card Board Mask ROM 2Mbit MBB38000-20P-G-2A6 MBB38000-20P-G-2A7 MB838000-20P-G-2A8	にはPrimary Board 及び Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board _B Board, Bender Board 及び (pcb 22925996) Program ROM PCM ROM-A PCM ROM-B	r Board	が含まれます。 ED Board. oardが含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17,	<u> </u>
7626637001 7626608000 IC 集積回 15209315 15209290 15209291 15209305 1517943250	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board include	Eti Primary Board & U Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board _B Board, Bender Board & U (pcb 22925996) Program ROM PCM ROM-A PCM ROM-B PCM ROM-C D-RAM	r Board	が含まれます。 ED Board. oardが含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB	· · · · · · · · · · · · · · · · · · ·
7626637001 7626608000 IC 集積回 15209315 15209290 15209305 1517943250 15199765	注:Power Supply Board Switch A Board Switch C Board Note:SWC Board include 注:SWC Board にはSW Card Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask	にはPrimary Board 及び Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board _B Board, Bender Board 及 (pcb 22925996) Program ROM PCM ROM-A PCM ROM-B PCM ROM-C D-RAM	r Board d and L KLED B	が含まれます。 ED Board. oardが含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB	
7626637001 7626608000 IC 集積回 15209315 15209290 15209291 15209305 1517943250 15199765 15199742	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board include	Ctl Primary Board & Cf Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board & C (pcb 22925996) Program ROM PCM ROM-A PCM ROM-B PCM ROM-C D-RAM CPU CPU	r Board d and L kLED B chip	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC5 on MB	
7626637001 7626608000 1C 集積回 15209315 15209290 15209291 15209305 1517943250 15199765 15199742 15239120	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board include Inc	にはPrimary Board 及び Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board 及び (pcb 22925996) Program ROM PCM ROM-A PCM ROM-B PCM ROM-C D-RAM	chip	が含まれます。 ED Board. oardが含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC5 on MB IC5 on MB IC51 on MB	· · · · · · · · · · · · · · · · · · ·
7626637001 7626608000 IC 集積回 15209291 15209291 15209205 1517943250 15199765 15199742 15239120 15239162	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board Note:SW_C Board include 注:SW_C Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC220AF-001	にはPrimary Board 及び Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board 及りを 22925996) Frogram ROM PCM ROM-A PCM ROM-B PCM ROM-C D-RAM	chip chip chip chip	が含まれます。 ED Board. oardが含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC5 on MB IC21 on MB IC21 on MB IC22 on MB	· · · · · · · · · · · · · · · · · · ·
7626637001 7626608000 IC 集積回 15209315 15209290 15209305 1517943250 15199765 15199742 15239120 15239162 15239124	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board Note:SW_C Board include 注:SW_C Board Mask ROM 2Mbit MBB38000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC220AF-001 SSC1000	Eti Primary Board & U Jumpe (pcb 22925995) (pcb 22925996) S SW_B Board, Bender Board B Board, Bender Board & U (pcb 22925996) Program ROM PCM ROM-A PCM ROM-A PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell	chip chip chip chip chip	が含まれます。 ED Board. oardが含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC5 on MB IC21 on MB IC22 on MB IC21 on MB IC21 on MB	
7626637001 7626608000 1C 集積回 15209315 15209290 15209291 15209305 1517943250 15199765 15199742 15239120 15239162 15239162 15239124	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board include	にはPrimary Board 及び Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board 及りを 22925996) Frogram ROM PCM ROM-A PCM ROM-B PCM ROM-C D-RAM	chip chip chip chip chip chip	が含まれます。 ED Board. oardが含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC5 on MB IC21 on MB IC21 on MB IC22 on MB	
7626637001 7626608000 1C 集積回 15209315 15209290 15209291 15209305 1517943250 15199742 15239120 15239120 15239162 15239168 15239169	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board Note:SW_C Board include 注:SW_C Board Mask ROM 2Mbit MBB38000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC220AF-001 SSC1000	Eti Primary Board & U Jumpe (pcb 22925995) (pcb 22925996) S SW_B Board, Bender Board & U (pcb 22925996) Program ROM PCM ROM-A PCM ROM-B PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell	chip chip chip chip chip	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC21 on MB IC21 on MB IC21 on MB IC11 on MB IC21 on MB IC11 on MB IC11 on MB IC24 on MB	
7626637001 7626608000 1C 集積回 15209315 15209290 15209291 15209305 1517943250 15199765 15199742 15239120 15239162 15239162 15239164	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board include 注:SW_C Board include Includ	にはPrimary Board 及び Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board 及び(pcb 22925996) Program ROM PCM ROM-A PCM ROM-B PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Standard cell	chip chip chip chip chip chip chip	が含まれます。 ED Board. oardが含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC21 on MB IC21 on MB IC21 on MB IC22 on MB IC11 on MB IC22 on MB IC11 on MB IC23 on MB	· · · · · · · · · · · · · · · · · · ·
7626637001 7626608000 IC 集積回 15209315 15209291 15209291 15209305 1517943250 15199765 15199765 15199742 15239120 15239124 15239168 15239168 15239169 15239147	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board Note:SW_C Board include 注:SW_C Board include 注:SW_C Board Mask ROM 2Mbit MBB38000-20P-G-2A6 MB838000-20P-G-2A6 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC20AF-001 SSC1000 MB87731A EP MB87424A H662E11B23FS HG62E11B23FS	Cti Primary Board & Cf Jumpe (pcb 22925995) (pcb 22925996) S SW_B Board, Bender Board & Cf (pcb 22925996) Program ROM PCM ROM-A PCM ROM-A PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Standard cell Gate array	chip chip chip chip chip chip chip chip	が含まれます。 ED Board. oardが含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC21 on MB IC21 on MB IC21 on MB IC22 on MB IC11 on MB IC24 on MB IC23 on MB IC30 on MB	
7626637001 7626608000 1C 集積回 15209315 15209290 15209291 15209305 1517943250 15199765 16199742 15239120 15239124 15239169 15239169 15239169 15239147	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board Note:SW_C Board include:注:SW_C Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC220AF-001 SSC1000 MB87731A EP MB87424A HG62E11B23FS HG62E11B23FS HG62E11B23FS	Eti Primary Board & U Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board B Board, Bender Board & U (pcb 22925996) Program ROM PCM ROM-A PCM ROM-A PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Gate array Gate array	chip chip chip chip chip chip chip chip	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC21 on MB IC21 on MB IC22 on MB IC11 on MB IC22 on MB IC11 on MB IC23 on MB IC11 on MB IC24 on MB IC23 on MB IC23 on MB IC23 on MB IC33 on MB IC33 on MB IC33 on MB IC33 on MB	
7626637001 7626608000 1C 集積回 15209315 15209290 15209305 1517943250 15199765 15199765 15139120 15239162 15239168 15239169 15239147 15235149 15259701T0	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board Note:SW_C Board include:注:SW_C Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC220AF-001 SSC1000 MB87731A EP MB87424A HG62E11B23FS HG62E11B23FS HG62E11B23FS	Eti Primary Board & U Jumpe (pcb 22925995) (pcb 22925996) S SW_B Board, Bender Board & U (pcb 22925996) Program ROM PCM ROM-A PCM ROM-B PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Gate array Gate array CMOS	chip chip chip chip chip chip chip chip	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC30 on MB IC20 on MB IC21 on MB IC21 on MB IC21 on MB IC11 on MB IC21 on MB IC11 on MB IC22 on MB IC11 on MB IC23 on MB IC23 on MB IC23 on MB IC33 on MB IC33 on MB IC33 on MB IC32 and IC37 on MB	· · · · · · · · · · · · · · · · · · ·
7626637001 7626608000 1C 集積回 15209315 15209290 15209305 1517943250 15199765 15199765 15139120 15239162 15239168 15239169 15239147 15235149 15259701T0	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board Note:SW_C Board include 注:SW_C Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC20AF-001 SSC1000 MB87731A EP MB87424A H662E11B23FS HG62E11B23FS HG62E11B23FS TC74HC00F-T2 TC74HCU04F-T2	Eti Primary Board & U Jumpe (pcb 22925995) (pcb 22925996) S SW_B Board, Bender Board & U (pcb 22925996) Program ROM PCM ROM-A PCM ROM-B PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Gate array Gate array CMOS	chip chip chip chip chip chip chip chip	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC20 on MB IC21 on MB IC21 on MB IC21 on MB IC21 on MB IC22 on MB IC11 on MB IC22 on MB IC23 on MB IC30 on MB IC30 on MB IC30 on MB IC30 on MB IC31 on MB IC32 on MB IC32 on MB IC33 on MB IC33 on MB IC32 and IC37 on MB IC7, IC20, IC27, IC33	· · · · · · · · · · · · · · · · · · ·
7626637001 7626608000 IC 集積回 15209315 15209291 15209305 1517943250 15199765 15199742 15239162 15239162 15239168 15239168 15239169 15239147 15235149 1525970170 1525970670	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board Note:SW_C Board include 注:SW_C Board include 注:SW_C Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC220AF-001 SSC1000 MB87731A EP MB87424A HG62E11B23FS HG62E11B23FS HG62E11B23FS TC74HC00F-T2 TC74HCU04F-T2	Eti Primary Board & Cf Jumpe (pcb 22925995) (pcb 22925996) S SW_B Board, Bender Board & Cf (pcb 22925996) Program ROM PCM ROM-A PCM ROM-A PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Standard cell Gate array Gate array CMOS CMOS	chip chip chip chip chip chip chip chip	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC25 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC5 on MB IC21 on MB IC22 on MB IC11 on MB IC22 on MB IC13 on MB IC23 on MB IC13 on MB IC23 on MB IC33 on MB IC35 on MB IC35 on MB	
7626637001 7626608000 1C 集積回 15209315 15209291 15209305 1517943250 15199765 15199765 15139162 15239162 15239168 15239169 15239147 15235149 1525970670 1525970670	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board Note:SW_C Board include 注:SW_C Board include 注:SW_C Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC220AF-001 SSC1000 MB87731A EP MB87424A HG62E11B23FS HG62E11B23FS TC74HC00F-T2 TC74HCU04F-T2	Eti Primary Board & U Jumpe (pcb 22925995) (pcb 22925996) S SW_B Board, Bender Board & U B Board, Bender Board & U (pcb 22925996) Program ROM PCM ROM-A PCM ROM-A PCM ROM-B PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Standard cell Gate array Gate array CMOS CMOS CMOS	chip chip chip chip chip chip chip chip	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC21 on MB IC21 on MB IC22 on MB IC11 on MB IC22 on MB IC11 on MB IC23 on MB IC33 on MB IC33 on MB IC35 on MB IC36 on MB IC37 on MB IC37 on MB IC37 on MB IC37 on MB IC38 on MB IC38 on MB	
7626637001 7626608000 1C 集積回 15209315 15209290 15209291 15209305 1517943250 15199742 15239120 15239120 15239124 15239168 15239147 15235149 1525970170 1525970670	注:Power Supply Board Switch A Board Switch C Board Note:SWC Board Note:SWC Board include 注:SWC Board include 注:SWC Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC235C260AF-002 TC24SC220AF-001 SSC1000 MB87731A EP MB87424A HG62E11B23FS HG62E11B24FS TC74HC00F-T2 TC74HCU04F-T2	にはPrimary Board 及び Jumpe (pcb 22925995) (pcb 22925996) s SW_B Board, Bender Board 及び (pcb 22925996) Program ROM PCM ROM-A PCM ROM-A PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Standard cell Gate array Gate array CMOS CMOS CMOS CMOS CMOS	r Board d and L KLED B chip chip chip chip chip chip chip chi	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC5 on MB IC5 on MB IC21 on MB IC21 on MB IC22 on MB IC22 on MB IC23 on MB IC33 on MB IC33 on MB IC35 on MB IC35 on MB IC36 on MB IC37 on MB IC37 on MB IC38 on MB IC39 on MB IC39 on MB IC30 on MB IC30 on MB IC30 on MB IC4 on MB IC50 on MB IC51 on MB IC60 on MB IC60 on MB IC70 on MB	
7626637001 7626608000 IC 集積回 15209291 15209291 15209291 15209291 15209291 15209291 15209291 15209291 15209291 15239120 15239124 15239168 15239169 15239147 15235149 15259701T0 15259701T0 15259711T0 15259716T0 15259711T0	注: Power Supply Board Switch A Board Switch C Board Note: SW_C Board Note: SW_C Board include 注: SW_C Board include 注: SW_C Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC220AF-001 SSC1000 MB87731A EP MB87424A HG62E11B23FS HG62E11B23FS HG62E11B24FS TC74HC00F-T2 TC74HCU04F-T2 TC74HC14F-T2 TC74HC14F-T2 BU4051BF T-2	Cti Primary Board & Cf Jumpe (pcb 22925995) (pcb 22925996) S SW_B Board, Bender Board & Cf Deb 22925996) Program ROM PCM ROM-A PCM ROM-A PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Standard cell Gate array Gate array CMOS CMOS CMOS CMOS CMOS CMOS CMOS CMOS	r Board I and L Chip chip	が含まれます。 ED Board. oardが含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC21 on MB IC21 on MB IC21 on MB IC22 on MB IC11 on MB IC24 on MB IC23 on MB IC23 on MB IC23 on MB IC23 on MB IC35 on MB IC35 on MB IC35 on MB IC36 on MB IC37 on MB IC37 on MB IC7, IC20, IC27, IC33 and IC35 on MB IC60 on MB IC10 on MB IC10 on MB IC11 on MB IC12 on MB	
7626637001 7626608000 IC 集積回 15209315 15209290 15209291 15209305 1517943250 15199765 15199742 15239120 15239162 15239169 15239169 15239147 15235149 1525970170 1525971670 1525971670 1525971670 1525971670	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board Note:SW_C Board include 注:SW_C Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A6 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC20AF-001 SSC1000 MB87731A EP MB87424A H662E11B23FS HG62E11B23FS HG62E11B24FS TC74HC00F-T2 TC74HCU04F-T2 TC74HC14F-T2 TC74HC32F-T2 BU4061BF T-2 HN62256LFP-12SLT	Eti Primary Board & U Jumpe (pcb 22925995) (pcb 22925996) S SW_B Board, Bender Board B Board, Bender Board & U (pcb 22925996) Program ROM PCM ROM-A PCM ROM-A PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Standard cell Standard cell Gate array Gate array CMOS CMOS CMOS CMOS CMOS S-RAM	chip chip chip chip chip chip chip chip	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC5 on MB IC5 on MB IC21 on MB IC21 on MB IC22 on MB IC22 on MB IC23 on MB IC33 on MB IC33 on MB IC35 on MB IC35 on MB IC36 on MB IC37 on MB IC37 on MB IC38 on MB IC39 on MB IC39 on MB IC30 on MB IC30 on MB IC30 on MB IC4 on MB IC50 on MB IC51 on MB IC60 on MB IC60 on MB IC70 on MB	
7626637001 7626608000 1C 集積回 15209315 15209305 15209305 1517943250 15199765 15199765 15139162 15239162 15239168 15239169 15239147 15235149 15259706T0 15259716T0 15259716T0 15259706T0 15259706T0	注:Power Supply Board Switch A Board Switch C Board Note:SW_C Board Note:SW_C Board include 注:SW_C Board include 注:SW_C Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A6 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC220AF-001 SSC1000 MB87731A EP MB87424A HG62E11B23FS HG62E11B23FS HG62E11B24FS TC74HC00F-T2 TC74HC04F-T2 TC74HC14F-T2 TC74HC14F-T2 HN62256LFP-12SLT UPD4062G	Eti Primary Board & U Jumpe (pcb 22925995) (pcb 22925996) S SW_B Board, Bender Board & U B Board, Bender Board & U (pcb 22925996) Program ROM PCM ROM-A PCM ROM-B PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Standard cell Gate array CMOS CMOS CMOS CMOS CMOS CMOS CMOS S-RAM Op-Amp	chip chip chip chip chip chip chip chip	が含まれます。 ED Board. oardが含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC21 on MB IC21 on MB IC22 on MB IC11 on MB IC23 on MB IC13 on MB IC23 on MB IC13 on MB IC23 on MB IC13 on MB IC24 on MB IC25 on MB IC26 on MB IC27, IC20, IC33 IC37 on MB IC40 on MB IC50 on MB IC60 on MB IC60 on MB IC61 on MB IC61 on MB IC61 on MB IC62 on MB IC62 on MB IC63 on MB IC63 on MB IC64 on MB IC65 on MB IC65 on MB IC66 on MB IC67 on MB IC67 on MB IC67 on MB IC68 on MB IC69 on MB	
7626637001 7626608000 1C 集積回 15209290 15209291 15209305 1517943250 15199742 15239120 15239124 15239168 15239169 15239147 15235149 15259701T0 15259701T0 15259716T0 15259716T0 15259101 15279508	注:Power Supply Board Switch A Board Switch C Board Note:SWC Board Note:SWC Board include 注:SWC Board include 注:SWC Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC220AF-001 SSC1000 MB87731A EP MB87424A HG62E11B23FS HG62E11B23FS HG62E11B23FS TC74HC00F-T2 TC74HCU0F-T2 TC74HCU0F-T2 TC74HC14F-T2 TC74HC14F-T2 BU4051BF T-2 HN62256LFP-12SLT uPD4062G BA15218 T-2	Eti Primary Board & U Jumpe (pcb 22925995) (pcb 22925996) S SW_B Board, Bender Board & C (pcb 22925996) Program ROM PCM ROM-A PCM ROM-A PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Standard cell Standard cell Gate array Gate array CMOS CMOS CMOS CMOS CMOS CMOS CMOS CMOS	chip chip chip chip chip chip chip chip	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC26 on MB IC36 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC36 on MB IC21 on MB IC22 on MB IC21 on MB IC22 on MB IC21 on MB IC22 on MB IC23 on MB IC33 on MB IC33 on MB IC32 on MB IC34 on MB IC4 on MB IC54 on MB IC55 on MB IC67 on MB IC75 on MB IC77 on MB IC77 on MB IC88 IC10 on MB IC89 IC10 on MB IC89 IC10 on MB IC89 IC10 on MB IC80 IC10 on JB IC10 on JB	
7626637001 7626608000 1C 集積回 15209315 15209290 15209291 15209305 1517943250 15199765 16199742 15239124 15239124 15239168 15239169 15239147 15235149 15259701T0 15259701T0 15259711T0 15259711T0 15259711T0 15259711T0 15259711T0 15259711T0 15259711T0 15259110 15279608 15289110 15189197	注: Power Supply Board Switch A Board Switch C Board Note: SW_C Board Note: SW_C Board Note: SW_C Board include : SW_C Board Mask ROM 2Mbit MB838000-20P-G-2A6 MB838000-20P-G-2A7 MB838000-20P-G-2A8 LH2464-10 H8/532 Mask H8/330 Mask TC23SC260AF-002 TC24SC220AF-001 SSC1000 MB87731A EP MB87424A HG62E11B23FS HG62E11B24FS TC74HC00F-T2 TC74HCU04F-T2 TC74HC14F-T2 TC74HC14F-T2 TC74HC32F-T2 BU4051BF T-2 HN62256LFP-12SLT uPD4062G BA1521B T-2 NJM5532D	Eti Primary Board & Cf Jumpe (pcb 22925995) (pcb 22925996) S SW_B Board, Bender Board & Cf (pcb 22925996) Program ROM PCM ROM-A PCM ROM-A PCM ROM-C D-RAM CPU CPU Standard cell Standard cell Standard cell Standard cell Standard cell Gate array Gate array CMOS CMOS CMOS CMOS CMOS CMOS S-RAM Op-Amp Op-Amp Op-Amp Op-Amp	chip chip chip chip chip chip chip chip	が含まれます。 ED Board. oard が含まれます。 IC31 on MB IC25 on MB IC26 on MB IC1 on CB IC14, IC15, IC16, IC17, IC18 and IC19 on MB IC30 on MB IC21 on MB IC22 on MB IC11 on MB IC22 on MB IC11 on MB IC24 on MB IC23 on MB IC24 on MB IC25 on MB IC26 on MB IC13 on MB IC27, IC27, IC33 and IC35 on MB IC6 on MB IC7, IC20, IC27, IC33 and IC35 on MB IC4 on MB IC4 on MB IC4 on MB IC4 on MB IC29 and IC30 on MB IC34 on MB IC8-IC10 on MB	

15189231 15209160			
	NIMAGGED	0- 4	IC8 on JB
	NJM4565D PCM61	Op-Amp D/A converter	IC11 on JB
		TTL	IC10 on JB
15169304H0	HD74LS04P		IC3 on PSB
15199184	AN78M15F	V.RGL + 15V	
15199185	AN79M15F	V.RGL - 15V	IC4 on PSB
15199137	AN7805F	V.RGL +5V	IC2 on PSB
15199256	TA78L005P-TPE6	V.RGL +5V	IC1 on MB
			IC14 on JB
15199172	TA79L005P-TPE6	V.RGL -5V	IC15 on JB
15219183	M51953AL	Reset	IC1 on PSB
15169596	TC74HC4051	CMOS	IC13 on JB
15159113D0	BU4051B	CMOS	IC4-IC6 on VLB
			IC4-IC7 on VRB
15229718	6N137	Photo Couppler	IC9 on JB
		Thoro couppier	100 on 15
1E200602	トランジスター	chin	Q5 on MB
15309603 15309101	2SB1197K 2SA1037KR	chip chip	Q8 on MB
15319101	2SC2412KR	chip	Q1, Q2, Q3, Q7 on MB
15329503	DTA-124EK	chip	Q4 on MB
15329516	DTC-114EK	chip	Q6 on MB
15119135	2SA1115-TP-E		Q13 on JB
15129156	2SC2603-TP-E		Q11, Q12, Q14 on JB
15129164	DTC-114ES-TP		Q10 on JB
15129168	DTC-124ES-TP		Q7 on JB
15129198	DTA-124ES-TP		Q8. Q9 on JB
15129194	DTC314-TS-TP		Q1-Q6 on JB
15259901	TD62385AF (EL)	Driver	IC2 on MB
15259902	TD62783AF (EL)	Driver	IC3 on MB
DIODE ダイ	オード		
15339103	MA153	chip	D1, D3 on MB
15339105	DAN-202K	chip	D2, D4 on MB
15019125	1SS133	omp	D1-D6 on JB
15015125	133133		D1-D4 on VRB
			D1-D16 on SAB
			D1-D3 on SBB
			D1-D26 on SCB
			D1-D3 on BB
15019281	1SR35-100A		D3-D5 on PSB
15019245	1B4B41	Diode bridge	D2 on PSB
15019273	4B4B41-LC1	Diode bridge	D1 on PSB
15019142	DAN-801	Diode Array	DA1 and DA4 on MB
15019154	DAP-801	Diode Array	DA2 and DA3 on MB
45000050	GL3HS8	LED	LED1-LED29 on VLB
15029259			LED1-LED9 on VRB
15029259			
15029259			LED1-LED6 on SAB
15029259			LED1-LED3 on BB
			LED1-LED6 on SAB LED1-LED3 on BB
RESISTOR	抵抗	Due godine	LED1-LED3 on BB
RESISTOR 12559736	ERQ12HJR22P 0.22ohm	Fuse resistor	LEDI-LED3 on BB
12559736 15399932	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip	Resistor Array	R1 on PSB RA9 and RA10 on MB
RESISTOR 12559736	ERQ12HJR22P 0.22ohm		RI on PSB RA9 and RA10 on MB RA15-RA17 on MB
12559736 15399932	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip	Resistor Array	R1 on PSB RA9 and RA10 on MB
12559736 15399932 15399942	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip	Resistor Array Resistor Array	RI on PSB RA9 and RA10 on MB RA15-RA17 on MB
12559736 15399932 15399942 15399917	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip	Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB
12559736 15399932 15399942 15399917 15399907	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip	Resistor Array Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA33,RA34,RA40,RA41 on MB
12559736 15399932 15399942 15399917	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A104 100k × 4 chip	Resistor Array Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA33,RA34,RA40,RA41 on MB RA7 on MB
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A154 100k × 4 chip RGLD4X223J 22k × 4	Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA33,RA34,RA40,RA41 on MB
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A104 100k × 4 chip RGLD4X223J 22k × 4	Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA7 on MB RA1 on JB
RESISTOR 12559736 15399932 15399942 15399917 15399907 15399935 13910114	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A154 100k × 4 chip RGLD4X223J 22k × 4	Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A104 100k × 4 chip RGLD4X223J 22k × 4	Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A104 100k × 4 chip RGLD4X223J 22k × 4	Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA33,RA34,RA40,RA41 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10,
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A104 100k × 4 chip RGLD4X223J 22k × 4	Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A104 100k × 4 chip RGLD4X223J 22k × 4	Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA33,RA34,RA40,RA41 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10,
RESISTOR 12559736 15399932 15399942 15399917 15399907 15399935 13910114	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A104 100k × 4 chip RGLD4X223J 22k × 4	Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA33,RA34,RA40,RA41 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16,
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A104 100k × 4 chip RGLD4X223J 22k × 4	Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA33,RA34,RA40,RA41 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339481	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A154 100k × 4 chip MR34J5A154 22k × 4 R 可変抵抗 EWA-NPE×05B15 (100kB)	Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA33,RA34,RA40,RA41 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A103E 1680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 R 可変抵抗 EWA-NPE×05B15 (100kB)	Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA7 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18,
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339481	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A154 100k × 4 chip MR34J5A154 22k × 4 R 可変抵抗 EWA-NPE×05B15 (100kB)	Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA33,RA34,RA40,RA41 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339481	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A103E 1680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 R 可変抵抗 EWA-NPE×05B15 (100kB)	Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32.RA35-RA39.RA42.RA43 on MB RA33,RA34.RA40.RA41 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339481	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A103E 1680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 R 可変抵抗 EWA-NPE×05B15 (100kB)	Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR27-On VLB VR1,VR6,VR7,VR11,VR14,VR15,
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339481	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A103E 1680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 R 可変抵抗 EWA-NPE×05B15 (100kB)	Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32.RA35-RA39.RA42.RA43 on MB RA33,RA34.RA40.RA41 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339481	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A103E 1680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 R 可変抵抗 EWA-NPE×05B15 (100kB)	Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR27-On VLB VR1,VR6,VR7,VR11,VR14,VR15,
12559736 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339481	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A103E 1680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 R 可変抵抗 EWA-NPE×05B15 (100kB)	Resistor Array	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR1,VR6,VR7,VR11,VR14,VR15, VR1,VR6,VR7,VR11,VR14,VR15, VR1,VR9,VR7,VR11,VR14,VR15, VR1,VR19,VR21,VR21,VR23,VR24 and
RESISTOR 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339481	ERQ12HJR22P 0.22ohm MNR34J5A101 100 × 4 chip MNR34J5A681 680 × 4 chip MNR34J5A103E 10k × 4 chip MNR34J5A153E 15k × 4 chip MNR34J5A153E 15k × 4 chip MR34J5A153E 22k × 4 P 可変抵抗 EWA-NPE×05B15 (100kB) EWANPK×A3B15 (100kB with center click)	Resistor Array Slider	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32.RA35-RA39,RA42,RA43 on MB RA33,RA34.RA40,RA41 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR1,VR6,VR7,VR11,VR14,VR15, VR17,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB
1259736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339483	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A103E 1680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 R 可変抵抗 EWA-NPE×05B15 (100kB) EWANPK × A3B15 (100kB with center click)	Resistor Array Slider Slider Slider	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA7 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR1,VR6,VR7,VR11,VR14,VR15, VR17,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB VR1-VR4,VR7,VR11,VR14,VR15, VR17,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB
RESISTOR 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339483 13359366 13289133 13299221	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A1681 680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X22J 22k × 4 P 可変抵抗 EWA-NPE×05B15 (100kB) EWANPO×05B14 (10kB stereo) RK11K113 (100kB) RVF6P51-5-503N (50kB)	Resistor Array Slider Slider Slider Rotary Trimmer	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA33,RA34,RA40,RA41 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR1,VR6,VR7,VR11,VR14,VR15, VR17,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB VR15,VR17 on VLB VR1,VR16,VR17 on VLB VR1 on JB
1259736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339483	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A103E 1680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 R 可変抵抗 EWA-NPE×05B15 (100kB) EWANPK × A3B15 (100kB with center click)	Resistor Array Slider Slider Slider	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA7 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR1,VR6,VR7,VR11,VR14,VR15, VR17,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB VR1-VR4,VR7,VR11,VR14,VR15, VR17,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB
RESISTOR 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339483 13359366 13389133 13299221	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A1681 680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X22J 22k × 4 P 可変抵抗 EWA-NPE×05B15 (100kB) EWANPO×05B14 (10kB stereo) RK11K113 (100kB) RVF6P51-5-503N (50kB)	Resistor Array Slider Slider Slider Rotary Trimmer	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR1,VR6,VR7,VR11,VR14,VR15, VR17,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB VR15,VR17 on VLB VR1,VR16,VR17,VR11,VR14,VR15, VR17,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB VR15,VR17 on VLB VR1 on JB
RESISTOR 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339483 13359366 13289133 13299221 13299202 EAPACITOR	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A103E 1680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 R 可変抵抗 EWA-NPE × 05B15 (100kB) EWANPK × A3B15 (100kB with center click) EWANPO × 05B14 (10kB stereo) RK11K113 (100kB) RVF6F51-5-503N (50kB) EVN-D4AA00 B23 (2kB)	Resistor Array Slider Slider Slider Rotary Trimmer	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR1,VR6,VR7,VR11,VR14,VR15, VR11,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB VR1 on BB VR1 on BB VR1 on BB VR1 on JB VR1 on JB VR1 on JB VR1 on JB VR1 on MB
RESISTOR 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339481 13359366 13289133 13299221 13299202 PAPACITOR 13639194\$0	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A101 100 × 4 chip MRR34J5A103E 100 × 4 chip MRR34J5A103E 100 × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 R 可変抵抗 EWA-NPE×05B15 (100kB) EWANPO×05B14 (10kB stereo) RK11K113 (100kB) RVF6F51-5-503N (50kB) EVN-D4AA00 B23 (2kB) コンデンサー 35MV1000HA4	Resistor Array Slider Slider Slider Trimmer Trimmer Electrolytic	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA33,RA34,RA40,RA41 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR1,VR6,VR7,VR11,VR14,VR15, VR17,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB VR15,VR17 on VLB VR1 on JB VR1 on JB VR1 on MB
12559736 15399932 15399942 15399917 15399907 15399935 13910114 20TENTIOMETE 13339481 13359366 13289133 13299221 13299202 24PACITOR 1363919450 13649672M0	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A1681 680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 B 可変抵抗 EWA-NPE×05B15 (100kB) EWANPO×05B14 (10kB stereo) RK11K113 (100kB) RVF6F51-5-503N (50kB) EVN-D4AA00 B23 (2kB) コンデンサー 35MV1000HA4 ECEA1EV682X	Resistor Array Slider Slider Slider Trimmer Trimmer Electrolytic Electrolytic	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR1,VR6,VR7,VR11,VR14,VR15, VR17,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB VR15,VR17 on VLB VR1 on JB VR10 on JB
RESISTOR 12559736 15399932 15399942 15399917 15399907 15399935 13910114 POTENTIOMETE 13339481 13339483 13359366 13289133 13299221 13299202 2222 224PACITOR 13639194S0 △13529104	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A103E 1680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 R 可変接抗 EWA-NPE×05B15 (100kB) EWANPK × A3B15 (100kB with center click) EWANPO×05B14 (10kB stereo) RK11K113 (100kB) RVF6F51-5-503N (50kB) EVN-D4AA00 B23 (2kB) コンデンサー 35MV1000HA4 ECEA1EV682X DE7150F472MVA1 (KC472m)	Resistor Array Slider Slider Slider Clietrolytic Electrolytic Line bypass	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR1,VR6,VR7,VR11,VR14,VR15, VR17,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB VR1 on MB
12559736 15399932 15399942 15399917 15399907 15399935 13910114 20TENTIOMETE 13339481 13359366 13289133 13299221 13299202 20PACITOR 1363919450 13649672M0	ERQ12HJR22P 0.22ohm MRR34J5A101 100 × 4 chip MRR34J5A1681 680 × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 10k × 4 chip MRR34J5A103E 15k × 4 chip MRR34J5A104 100k × 4 chip RGLD4X223J 22k × 4 B 可変抵抗 EWA-NPE×05B15 (100kB) EWANPO×05B14 (10kB stereo) RK11K113 (100kB) RVF6F51-5-503N (50kB) EVN-D4AA00 B23 (2kB) コンデンサー 35MV1000HA4 ECEA1EV682X	Resistor Array Slider Slider Slider Trimmer Trimmer Electrolytic Electrolytic	R1 on PSB RA9 and RA10 on MB RA15-RA17 on MB RA1-RA6, RA8, RA11-RA14, RA18-RA32,RA35-RA39,RA42,RA43 on MB RA7 on MB RA1 on JB VR5,VR6,VR8,VR9-VR14,VR20 and VR24-VR26 on VLB VR2VR5,VR8-VR10, VR12,VR13,VR16, VR18,VR20,VR22,VR25 and VR27-32 on VRB VR1 on SBB VR1-VR4,VR7,VR16,VR18, VR19,VR21-VR23 and VR27 on VLB VR1,VR6,VR7,VR11,VR14,VR15, VR17,VR19,VR21,VR23,VR24 and VR26 on VRB VR1 on BB VR15,VR17 on VLB VR1 on JB VR10 nn JB

CAPACITOR	コンデンサー			WIRING, CABL	E ワイヤリング、ケーブル		
1363919450		Electrolytic	C5 and C6 on PSB	23485680	W-1	Wiring Assy	
13649672M0		Electrolytic	C4 on PSB	23485680	W-1 NOTE: Wiring Assy W-1 consist		

△13529104	DE7150F472MVA1 (KC472m)	Line bypass	C17 on PB		注 : ワイヤリング・アッセイ W-1		
13529115	EXF-P8101MW 100pF × 8	Capacitor Array	CA1 on MB		W-1-1 348-680	5p Cable	Between CN2 on PSB and CN11 on MB
13529224	EXF-P8102MZ $1000pF \times 8$	Capacitor Array	CA1-CA3 on VLB, CA1-CA4 on VRB		W-1-2 348-680	12p Cable	Between CN3 on PSB and CN6 on MB
*********	OIL, FILTER インダクター、コイル	コ . 4.み			W-1-3 348-680	14p Cable	Between CN1 on PSB and CN3 on JB
INDUCTOR, CO			The state of the s	- 23485681	W-2	Wiring Assy	
12449380	EXC-ELDR25V	Ferrite Bead	L1-L10, FL3, FL4, FL26 on MB		NOTE: Wiring Assy W-2 consist	of the following wirings.	
			L1-L9 on JB		注 : ワイヤリング・アッセイ W-2	は、下記のワイヤリングから	構成されます。
			L1 on CB		W-2-1 348-681	8p Cable	Between CN4 on VLB and CN2 on SAB
12449358	FL5R200N PNT	Coil	L10-L17 on JB		W-2-2 348-681	10p Cable	Between CN3 on VLB and CN1 on SAB
13529225	ELKTT121CA		FL19, FL24 on MB	23485682	W-3	Wiring Assy	
13529188	ELKTR101GA		FL30 on MB	20100002	NOTE: Wiring Assy W-3 consist		
13529221	ELKTT331IA		FL28 on MB		注:ワイヤリング・アッセイ W-3		構成されます。
13529187	ELKTT391CA		FL9-FL11 on MB		W-3-1 348-682	10p Cable	Between CN5 on VLB and CN1 on LB
			FL1-FL11 on IB		W-3-2 348-682	10p Cable	Between CN6 on VLB and CN1 on SBB
13529216	ELKTT470GA		FL5-FL8 on MB		W-3-3 348-682	12p Cable	Between CN2 on VLB and CN1 on MB
13529176	DSS306-93-F223Z16		FL1, FL2, FL12-FL18, FL20-FL23,	00405000			Detween Citz on VLD and Citi on MD
10020110	DOGGOO GO I DDODIO		FL25, FL27, FL29, FL31 on MB	23485683	W-4	Wiring Assy	Detween CNO on VDD and CNO on MD
12449369	PFB-2 4502-069		LC1-LC4 on JB		W-4-1 348-683	8p Cable	Between CN2 on VRB and CN2 on MB
12443003	11.0 2 4002-003		TOT TO OIL ID		W-4-2 348-683	12p Cable	Between CN3 on VRB and CN1 on SCB
CRYSTAL, RES	SONATOR クリスタル,発振子			23485684	W-5 348-684	10p Cable	Between CN5 on JB and CN10 on MB
		-1.1	V1 - 100	23485685	W-6	Wiring Assy	
15299132	MA-506 20.000MHz	chip	X1 on MB		NOTE: Wiring Assy W-6 consist		
15299148	MA-506 26.195MHz	chip	X3 on MB		注 : ワイヤリング・アッセイ W-6	は、下記のワイヤリングから	
15299149	MA-506 28.224MHz	chip	X2 on MB		W-6-1 348-685	3p Ribbon Cable	Between CN6 on JB and CN15 on MB
					W-6-2 348-685	5p Ribbon Cable	Between CN4 on JB and CN5 on MB
ENCODER	エンコーダー			- 23485686	W-7 348-686	7p Ribbon Cable	Between CN3 on CB and CN12 on MB
13289132	EVQWQ5F2024B	Rotary	ENC1 on EB	23485687	W-8 348-687	4p Ribbon Cable	Between CN7 on VLB and CN1 on EB
				23485688	W-9 348-688	6p Shielded	Between CN1 on JB and CN2 on BB
CONNECTOR	コネクター				W-10 348-689	8p Cable	Between CN3 on SAB and CN1 on BB
13429233	7508095A	34p Card connector	CN14 on MB	- 23485689			Between CN2 on CB and CN13 on MB
13429345	JC-20-C40P-LT1-A2	40p Card connector	CN1 on CB	23485690	30PIN FLATCABLE ASSY	30p Flat Cable	
13429192	PS-40PE-D4T1-B1	40p Card Connector	CN3 on MB	23485691	40PIN FLATCABLE ASSY	40p Flat Cable	Between CN1 on VRB and CN3 on MB
13429192	F3-40FE-D411-B1	40p Fili Headel		23485692	50PIN FLATCABLE ASSY	50p Flat Cable	Between CN1 on VLB and CN4 on MB
10000051	DC FADE DATA DA	FA 70' 17 1	CN1 on VRB	23485693	Preparing Wire	400mm	
13369851	PS-50PE-D4T1-B1	50p Pin Header	CN4 on MB	23485694	PS Preparing Lead		
			CN1 on VLB	23485695	PS Jumper Lead	5p Ribbon Cable	Between PSB and JUB
13439220	FCN724P030AU/0	30p Pin Header	CN13 on MB	23485696	Grounding Lead for 240V		240V
			CN2 on CB	23485879	SW_A Preparing Lead		
13439475	52004-0310	3p Wire Trap	CN15 on MB				
13439412	52004-0510	5p Wire Trap	CN5 on MB	TRANSFORME	R トランス		
13439410	52004-0710	7p Wire Trap	CN12 on MB	∆22455636U0		Power transformer	Universal
13369885	IL-FPC-26S-S1T1-SBN	26p	CN7 on MB	252240000000	DET 1611	1 ower transformer	Omversar
13369521	IL-S-3P-S2T2-EF-K63	3p Pin Header	CN8 on MB	AC INLET	ACインレット		
13369523	IL-S-5P-S2T2-EF-K41	5p Pin Header	CN11 on MB		·	0.0	1001/ 1171/ 2201/
13369526	IL-S-8P-S2T2-EF-K27	8p Pin Header	CN2 on MB	△13429710	PA-126	2P	100V, 117V, 230V
13369528	IL-S-10P-S2T2-EF-K22	10p Pin Header	CN10 on MB	△13429718	CM-11	3P	240V
13369530	IL-S-12P-S2T2-EF-K18	12p Pin Header			= :4.		
		-	CN1,CN6 on MB	BATTERY	電池		
13369532	IL-S-14P-S2T2-EF-K16	5p Pin Header	CN2 on PSB	△12569249	CR2032	Lithium + 3V	BT1 on MB
13439335	IL-S-6P-S2T2-EF	6p Pin Header	CN1, CN2 on JB				
			CN2 on BB	SCREW	k ジ類		
13439297	IL-S-8P-S2T2-EF	8p Pin Header	CN4 on VLB	******	3×6mm P.Tight Pan Head Fe.BC		
			CN2 on VRB	******	3×8mm P.Tight Pan Head Fe.BC		
			CN2, CN3 on SAB				
				******	3×8mm P.Tight Binding Fe.BC		
13439298	IL-S-10P-S2T2-EF	10p Pin Header	CN1 on BB	*******	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm		
13439298	IL-S-10P-S2T2-EF	10p Pin Header	CN1 on BB CN3, CN5, CN6 on VLB	******* ******* *******	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC		
13439298	IL-S-10P-S2T2-EF	10p Pin Header	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB	******* ******* *******	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC		
			CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB	******* ******* ******* *******	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC		
13439298 13439336	IL-S-10P-S2T2-EF IL-S-12P-S2T2-EF	10p Pin Header 12p Pin Header	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB	******* ******* *******	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC		
			CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VLB	******* ******* ******* *******	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC		
			CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VLB CN3 on VLB CN1 on SCB	******* ******* ******* *******	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC 3×6mm W SEMS Fe.Cm		
13439336	IL-S-12P-S2T2-EF	12p Pin Header	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN1 on SCB	******** ******* ******* ******* ******	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC 3×6mm W SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC		
			CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN3 on PSB CN3 on PSB CN3 on PSB CN3 on PSB	######################################	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC 3×6mm W SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC		
13439336 13439338	IL-S-12P-S2T2-EF IL-S-14P-S2T2-EF	12p Pin Header	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN1 on SCB	******** ******* ******* ******* ******	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC 3×6mm W SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC		
13439336	IL-S-12P-S2T2-EF	12p Pin Header	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN3 on PSB CN3 on PSB CN3 on PSB CN3 on PSB	######################################	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC 3×6mm W SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC		
13439336 13439338	IL-S-12P-S2T2-EF IL-S-14P-S2T2-EF	12p Pin Header	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN3 on PSB CN3 on JB CN1 on FSB CN1 on JB	######################################	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC 3×6mm W SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC		
13439336 13439338 13439355 13429293	IL-S-12P-S2T2-EF IL-S-14P-S2T2-EF IL-S-10P-S2L2-EF	12p Pin Header 14p Pin Header 10p Pin Header 4p Cable Holder	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN3 on PSB CN3 on PSB CN3 on JB CN1 on PSB CN1 on LB CN1 on VLB	######################################	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC 3×6mm W SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC US		
13439336 13439338 13439355 13429293 13369852	IL-S-12P-S2T2-EF IL-S-14P-S2T2-EF IL-S-10P-S2L2-EF 51048-0400 52151-0410	12p Pin Header 14p Pin Header 10p Pin Header 4p Cable Holder 4p Wire Trap	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VKB CN1 on SCB CN3 on PSB CN3 on PSB CN3 on JB CN1 on PSB CN1 on LB CN1 on LB CN7 on VLB	######################################	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC 3×6mm W SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC B KNOB HOLDER 1P B KNOB HOLDER 2P B KNOB HOLDER 3P B KNOB HOLDER 4P		
13439336 13439338 13439355 13429293 13369852 13439460	IL-S-12P-S2T2-EF IL-S-14P-S2T2-EF IL-S-10P-S2L2-EF 51048-0400 52151-0410 SD-51016-0300	12p Pin Header 14p Pin Header 10p Pin Header 4p Cable Holder 4p Wire Trap 3p Cable Holder	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN3 on PSB CN3 on JB CN1 on PSB CN1 on DSB	######################################	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC 3×6mm W SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC US その他 B KNOB HOLDER 1P B KNOB HOLDER 2P B KNOB HOLDER 2P B KNOB HOLDER 4P LED HOLDER 2P		·
13439336 13439338 13439355 13429293 13369852 13439460 13439462	IL-S-12P-S2T2-EF IL-S-14P-S2T2-EF IL-S-10P-S2L2-EF 51048-0400 52151-0410 SD-51016-0300 SD-51016-0500	12p Pin Header 14p Pin Header 10p Pin Header 4p Cable Holder 4p Wire Trap 3p Cable Holder 5p Cable Holder	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN3 on PSB CN3 on JB CN1 on DSB CN1 on EB CN1 on EB CN1 on EB CN6 on JB CN6 on JB	######################################	3 × 8mm P.Tight Binding Fe.BC 3 × 8mm B.Tight Binding Fe.Cm 3 × 8mm B.Tight Binding Fe.BC 4 × 8mm S.Tight Binding Fe.BC 4 × 8mm W SEMS BC 3 × 6mm W SEMS Fe.Cm 3 × 10 × 0.8mm Washer Fe.BC US		LED Saver
13439336 13439338 13439355 13429293 13369852 13439460	IL-S-12P-S2T2-EF IL-S-14P-S2T2-EF IL-S-10P-S2L2-EF 51048-0400 52151-0410 SD-51016-0300	12p Pin Header 14p Pin Header 10p Pin Header 4p Cable Holder 4p Wire Trap 3p Cable Holder	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN3 on PSB CN3 on JB CN1 on PSB CN1 on DSB	######################################	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W.SEMS BC 3×6mm W.SEMS BC 3×6mm W.SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC US		LED Spacer
13439336 13439338 13439355 13429293 13369852 13439460 13439462	IL-S-12P-S2T2-EF IL-S-14P-S2T2-EF IL-S-10P-S2L2-EF 51048-0400 52151-0410 SD-51016-0300 SD-51016-0500	12p Pin Header 14p Pin Header 10p Pin Header 4p Cable Holder 4p Wire Trap 3p Cable Holder 5p Cable Holder	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN3 on PSB CN3 on JB CN1 on DSB CN1 on EB CN1 on EB CN1 on EB CN6 on JB CN6 on JB	######################################	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC 3×6mm W SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC US		LED Spacer
13439336 13439338 13439355 13429293 13369852 13439460 13439462	IL-S-12P-S2T2-EF IL-S-14P-S2T2-EF IL-S-10P-S2L2-EF 51048-0400 52151-0410 SD-51016-0300 SD-51016-0500	12p Pin Header 14p Pin Header 10p Pin Header 4p Cable Holder 4p Wire Trap 3p Cable Holder 5p Cable Holder	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN3 on PSB CN3 on JB CN1 on DSB CN1 on EB CN1 on EB CN1 on EB CN6 on JB CN6 on JB	######################################	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC 3×6mm W SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC US €OME B KNOB HOLDER 1P B KNOB HOLDER 2P B KNOB HOLDER 3P B KNOB HOLDER 3P B KNOB HOLDER 4P LED HOLDER 2P LED HOLDER 2P LED HOLDER 4P LDS-120R Main Board Shield sheet Main Board Shield sheet Main Board Shield sheet		
13439336 13439338 13439355 13429293 13369852 13439460 13439462	IL-S-12P-S2T2-EF IL-S-14P-S2T2-EF IL-S-10P-S2L2-EF 51048-0400 52151-0410 SD-51016-0300 SD-51016-0500	12p Pin Header 14p Pin Header 10p Pin Header 4p Cable Holder 4p Wire Trap 3p Cable Holder 5p Cable Holder	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN3 on PSB CN3 on JB CN1 on DSB CN1 on EB CN1 on EB CN1 on EB CN6 on JB CN6 on JB	********* ******* ******* ******* ****	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W.SEMS BC 3×6mm W.SEMS BC 3×6mm W.SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC US その他 B KNOB HOLDER 1P B KNOB HOLDER 2P B KNOB HOLDER 3P B KNOB HOLDER 3P B KNOB HOLDER 4P LED HOLDER 2P LED HOLDER 4P LED HOLDER 4P LDS-120R Main Board Shield sheet Main Board Shield sheet B CR2032 Battery Holder		On MB
13439336 13439338 13439355 13429293 13369852 13439460 13439462	IL-S-12P-S2T2-EF IL-S-14P-S2T2-EF IL-S-10P-S2L2-EF 51048-0400 52151-0410 SD-51016-0300 SD-51016-0500	12p Pin Header 14p Pin Header 10p Pin Header 4p Cable Holder 4p Wire Trap 3p Cable Holder 5p Cable Holder	CN1 on BB CN3, CN5, CN6 on VLB CN1 on SAB CN1 on SBB CN2 on VLB CN3 on VRB CN1 on SCB CN3 on PSB CN3 on JB CN1 on DSB CN1 on EB CN1 on EB CN1 on EB CN6 on JB CN6 on JB	######################################	3×8mm P.Tight Binding Fe.BC 3×8mm B.Tight Binding Fe.Cm 3×8mm B.Tight Binding Fe.BC 4×8mm S.Tight Binding Fe.BC 4×8mm W SEMS BC 3×6mm W SEMS Fe.Cm 3×10×0.8mm Washer Fe.BC US €OME B KNOB HOLDER 1P B KNOB HOLDER 2P B KNOB HOLDER 3P B KNOB HOLDER 3P B KNOB HOLDER 4P LED HOLDER 2P LED HOLDER 2P LED HOLDER 4P LDS-120R Main Board Shield sheet Main Board Shield sheet Main Board Shield sheet		

ACCESSORIES	付属品			
△13439825	DC-320-J01	AC Cord	100V	
∆13439812F0	120V UC 704-J01	AC Cord	117V	
∆13439813F0	220V DNS EC210-J06	AC Cord	230V	
△23495110	57226604606	AC Cord	240V England	
∆13439814F0	SC415-J06	AC Cord	240V Australia	
23430675S0	LP-25 2.5m (PJ-1M)	LP Cord		
26045448	Owner's Manual Set (English)			
26045447	Owner's Manual Set (Japanese)			
OPTINONS	別売品			
* * * * * * * *	M-256E 256kbit RAM Card		DATA Card	



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40

E MAIN BOARD ASSY 7626690000 (pcb 22925990)

Apparatus containing Lithium batteries

ADVARSEL!

Lithiumbatteri – Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandøren.

ADVARSEL!


Lithiumbatteri – Eksplosjonsfare. Ved utskifting benyttes kun batteri som anbefalt av apparatfabrikanten. Brukt batteri returneres apparatleverandøren.

VARNING!

Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.


VAROITUS!

Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.




View from components side.

CIRCUIT DIAGRAM/回路図 MAIN BOARD (1/2)



7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40




VOLUME_L BOARD

ASSY 7626618001 (pcb 22925992)


NOTE : ____

Volume__L Board includes Encoder Board.

- 注意: _____ Volume_L BoardにはEncoder Boardが含まれます。 CIRCUIT DIAGRAM/回路図 ENCODER BOARD



ENCODER: EVQ-WQ5F20 24B




4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40

View from components side.


3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 CIRCUIT DIAGRAM/回路図

VOLUME_L BOARD




VOLUME R BOARD


ASSY 7626631001 (pcb 22925993)



3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40




JACK BOARDASSY 7626611000 (pcb 22925991)



View from components side.

3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 CIRCUIT DIAGRAM/回路図



SWITCH_A BOARD


ASSY 7626634001 (pcb 22925995)


SWITCH C BOARD ASSY 7626637001

SW C Board includes SW_B Board, Bender Board and LED Board.


SW_C BoardにはSW_B Board、Bender Board及びLED Board が含まれます。

3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40






View from components side.






LED BOARD (pcb 22925996)







BENDER BOARD (pcb 22925996)

SWITCH B BOARD (pcb 22925996)





View from components side.


CARD BOARD ASSY 7626608000 (pcb 22925996)

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40

CIRCUT DIAGRAMS/回路図









CN1 : JC-20-C40P-LT1-A2 CN2 : FCN-754P030-AU/0 CN3 : SD-51016-0700


L : EXC-ELDR25V

CIRCUIT DIAGRAMS/回路図





3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40



TEST MODE

The TEST MODE is entered by pressing [EXIT] while simultaneously holding down the [CURSOR ◀] and [CURSOR ▶] in the MULTI MODE.

Executing the operations below in the TEST MODE calls up the following TEST MODES.

テスト・モード

マルチモードにおいて [CURSOR ◀] と [CURSOR ▶] を押しながら [EXIT] を押すとテストモードに入ります。

テストモードにおいて,以下の操作をすると各テスト・モードに移ります。

EXIT + BANK1	Internal RAM test	内蔵RAMテスト
EXIT + BANK2	DATA card test	DATA カードテスト
EXIT + BANK3	Internal PCM ROM test	内蔵 PCM-ROM のテスト
EXIT + BANK4	WAVEFORM card test	WAVEFORM カードのテスト
EXIT + BANK5	Button test	ボタン・テスト
EXIT + BANK6	LED test	LEDテスト
EXIT + BANK7	Slider test	スライダー・テスト
EXIT + BANK8	Encoder test	エンコーダー・テスト
EXIT + NUMBER1	Bender & Aftertouch test	ベンダー・アフタータッチ・テスト
EXIT + NUMBER2	Pedal test	ペダル・テスト
EXIT + NUMBER3	Keyboard test	キーボード・テスト
EXIT + NUMBER4	MIDI test	MIDIテスト
EXIT + NUMBER5	Output test	出力テスト
EXIT + NUMBER6	Effect test	エフェクト・テスト
EXIT + NUMBER7	D/A adjustment	D/A調整
EXIT + NUMBER8	Exit test mode	テストモードの終了

[1] Internal RAM Test

- 1. Press [BANK 1] while holding down [EXIT].
- 2. The operation has been successfully completed if "OK" is displayed in the right side of the screen.

【1】内蔵 RAM テスト

1. [EXIT] を押しながら [BANK1] を押します。 2. 右画面に "OK" が表示されれば合格です。

Interbal RAM test

R/W Batt OK OK

When "NG" appears under R/W:

Refer to [2] 3 in the Troubleshooting section (p.34).

When "NG" appears under Batt:

Refer to [1] 3 in the Troubleshooting section (p.33).

R/WがNGの場合:

トラブルシューティングの【2】の3を参照して下さい。(P. 34)

Batt が NG の場合:

トラブルシューティングの【1】の3を参照して下さい(P. 33)。

[2] DATA Card Test

- 1. Press [BANK 2] while holding down [EXIT].
- 2. Insert a memory card such as the M-256E into the DATA CARD slot on the rear panel. (Turn off the memory protect switch.)
- 3. The test has been successfully completed if "OK" is displayed in the right side of the screen.

【2】データカードテスト

- 1. [EXIT] を押しながら [BANK2] を押します。
- 2.本体リアパネルのDATA CARDのスロットに、M-256E等のメ モリカードを挿入します(プロテクトスイッチをOFFにして下 さい)。
- 3. 右画面に "OK" が表示されれば合格です。

DATA card test Insert DATA card R/W Batt OK OK

When "NG" appears:

Refer to [2] 1 in the Troubleshooting section (p.34).

NGの場合

トラブルシューティングの【2】の1を参照して下さい (P. 34)。

[3] Internal PCM ROM Test

- 1.Press [BANK 3] while holding down [EXIT].
- 2. The test has been successfully completed if "OK" is displayed in the right side of the screen.

【3】内蔵PCM-ROMのテスト

1. [EXIT] を押しながら [BANK3] を押します。 2. 右画面に "OK" が表示されれば合格です。

Internal PCM ROMs

ROM1 ROM2 ROM3 OK OK OK

When "NG" appears:

Refer to [3] 1, 3, and 4 in the Troubleshooting section (p.38).

NG の場合:

トラブルシューティングの【3】の1、3、4を参照して下さい(P.38)。

[4] WAVEFORM card test

- 1. Press [BANK 3] while holding down [EXIT].
- 2.Insert the WAVEFORM card (SO-JD80) in the WAVE CARD slot on the rear panel.
- 3. Press a key on the keyboard within the range of C2—E3.4. If the name of the wave is correctly displayed and the sound comes out correctly, the test has been successfully completed.
- 5. Press a key on the keyboard within the range of F3—E5.6. If the name of the wave is correctly displayed and the sound comes out correctly, the test has been successfully completed.
- 7. Press a key on the keyboard within the range of F5—C7. 8. If the name of the wave is correctly displayed and the sound comes out correctly, the test has been successfully

【4】ウェーブフォームカードのテスト


- 1. [EXIT] を押しながら [BANK3] を押します。
- 2.本体リアパネルのWAVE CARDのスロットに、WAVEFORM カード (SO-JD80) を挿入します。
- 3. C2-E3 の鍵域で鍵盤を弾きます。
- 4. ウェーブの名前が正しく表示され、音が正しく鳴れば合格です。

5. F3-E5の鍵域で鍵盤を弾きます。

6. ウェーブの名前が正しく表示され、音が正しく鳴れば合格です。

7.F5-C7の鍵域で鍵盤を弾きます。

8. ウェーブの名前が正しく表示され、音が正しく鳴れば合格です。



WAVEFORM card test Insert WAVE card

|wavname(TOP) |C-001:EP_HARD

When it is inoperative:

completed.

Refer to [3] 1, 3, and 4 in the Troubleshooting section (p. 38).

NG の場合:

トラブルシューティングの【3】の1、3、4を参照して下さい (P.38)。

[5] Panel Button Test

- 1. Press [BANK 5] while holding down [EXIT].
- 2. Press each button on the panel in succession. If the name of the button you pressed and the ON/OFF status are correctly displayed, the test has been successfully completed.

【5】ボタン・テスト

- 1. [EXIT] を押しながら [BANK5] を押します。
- 2. 各ボタンを順に押し、押したボタンの名前とON/OFFが、各ボタンについて正しく表示されれば合格です。

Buttons test Push buttons

button [ON] TVF:MODE

When it is inoperative:

Refer to [2] 4 in the Troubleshooting section (p.34).

NG の場合:


トラブルシューティングの【2】の4を参照して下さい(P. 34)。

[6] LED Test

- 1. Press [BANK 6] while holding down [EXIT].
- Each LED will briefly light up in succession. If all the LEDs have lit up in succession, the test has been successfully completed.
- 3. The speed at which the LEDs light up and turn off can be adjusted by moving the bender to the right or left.

【6】LEDテスト

- 1. [EXIT] を押しながら [BANK6] を押します。
- 2.各LEDが順番に点灯・消灯していきます。全てのLEDが点灯・消灯すれば合格です。
- 3. ベンダーを左右に操作すると、点灯・消灯のスピードが調節できます。



When it is inoperative:

Refer to [2] 5 in the Troubleshooting section (p.35).

NG の場合:

トラブルシューティングの【2】の5を参照して下さい (P. 35)。

[7] Slider Test

- 1. Move all sliders down except for the volume.
- 2. Press [BANK 7] while holding down [EXIT].
- 3. The name and the value of each slider are displayed when each slider is moved up or down.
- 4. Sounds are output with the movement of the sliders, and the pitch changes. The sound stops when the slider is moved to the extreme positions, up or down.
- 5. If the names of the sliders are displayed correctly and the value changes from 00 to 127, and the pitch changes smoothly, the test has been successfully completed.

【7】スライダー・テスト

- 1.全てのスライダーを下におろしておきます (ボリュームは除きます)。
- 2. [EXIT] を押しながら [BANK7] を押します。
- 3.各スライダーを上下に動かすと、スライダーの名前と値が表示されます。
- 4. スライダーの動きとともに音が出て、ピッチが上下に変化します。 スライダーが上または下に行きつくと音は止まります。
- 5. スライダー名が正しく表示され、値が "00" ~ "127" まで正しく 変化し、かつピッチが滑らかに変化すれば合格です。

Sliders test Move Sliders

slider [127] PALETTE TONE A

When it is inoperative:

Refer to [2] 6 in the Troubleshooting section (p.35).

NG の場合:

トラブルシューティングの【2】の6を参照して下さい (P. 35)。

[8] Rotary Encoder Test

- 1. Press [BANK 8] while holding down [EXIT].
- 2. When the [WG WAVEFORM] knob is rotated, numbers are shown with the clicks.
- 3. The number increases when rotating the knob to the right, and decreases when rotated to the left. The number changes in the range of -50-00-+50.
- The number will change upon each click, according to the direction in which the knob is rotated.

【8】エンコーダー・テスト

- 1. [EXIT] を押しながら [BANK8] を押します。
- 2. [WG WAVEFORM] のツマミを回すと、クリックに合わせて数字が表示されます。
- 3. ツマミを右に回すと数字は大きくなり、左に回せば小さくなります。数字は "-50" \sim "00" \sim "+50" の範囲で変化します。
- 4.1 クリックにつき1つ、回す方向に応じて数字が変化すれば合格です。

Rotary encorder test Move WAVEFORM knob encorder [+50]

When it is inoperative:

Refer to [2] 7 in the Troubleshooting section (p.35).

NG の場合:

トラブルシューティングの【2】の7を参照して下さい (P. 35)。

[9] Bender & After Touch Test

- 1. Press [NUMBER 1] while holding down [EXIT].
- 2. Check that the number of BND changes in the range of -127-00-+127, by moving the bender lever to the right and left.
- 3. Press the bender lever in the modulation direction in order to confirm that the number of MOD changes from 00 to 127.
- 4. Press any key to check that the number of AFT changes from 00 to 127.

【9】ベンダー・アフタータッチ・テスト

- 1. [EXIT] を押しながら [NUMBER1] を押します。
- 2. ベンダーレバーを左右に動かし、BNDの数字が "-127" \sim "00" \sim "+ 127" と変化することを確認して下さい。
- 3.ベンダーレバーをモジュレーション側に押し込み、MODの数字が "00" ~ "127" と変化することを確認して下さい。
- 4.任意の鍵盤を押し込み、AFTの数字が "00" \sim "127" と変化することを確認して下さい。

Bender & A-touch Move lever & Press key BND MOD AFT +127 00 00

When it is inoperative:

Refer to [2] 8 in the Troubleshooting section (p.35).

NG の場合:

トラブルシューティングの【2】の8を参照して下さい(P. 35)。

[10] Pedal Test

- 1. Press [NUMBER 2] while holding down [EXIT].
- Connect the volume pedal (EV-5 or FV-60) to the EXT CONT lack on the rear panel.
- 3. Check that the value of EXT changes from 0 to 127 as the volume pedal is being pressed down.
- 4. Disconnect the volume pedal from the jack, and check that the value of the EXT becomes 127.
- 5. Connect the damper pedal (DP-2 or DP-6) to the HOLD PEDAL jack on the rear panel.
- 6. Check that the HOLD function is activated (or ON) when the damper pedal is pressed down, and that HOLD is cancelled (or OFF) when the pedal is released.

【10】ペダル・テスト

- 1, [EXIT] を押しながら [NUMBER2] を押します。
- 2.本体リアパネルのEXT CONTにボリューム・ペダル (EV-5またはFV-60) を接続します。
- 3. ボリューム・ペダルを踏み込んでいくにつれて、EXTの値が"O" から"127"に変化することを確認して下さい。
- 4. ボリュームル・ペダルのプラグを本体から抜き、EXT の値が "127" になることを確認して下さい。
- 5.本体リアパネルのHOLD PEDALにダンパー・ペダル (DP-2またはDP-6) を接続します。
- 6.ダンパー・ペダルを踏むと HOLDが "ON"、離すと HOLDが "OFF"と表示されることを確認して下さい。

Pedals test Move EXP & HOLD pedal

EXT HOLD 127 OFF When it is inoperative:

Refer to [2] 9 in the Troubleshooting section (p.37).

NGの場合:

トラブルシューティングの【2】の9を参照して下さい (P. 37)。

[11] Keyboard Test

- 1. Press [NUMBER 3] while holding down [EXIT].
- 2. If the correct key name and the velocity are displayed when the key is hit, the test has been successfully completed.

【11】キーボード・テスト

- 1. [EXIT] を押しながら [NUMBER3] を押します。
- 2. 鍵盤を弾き、正しいキー名とベロシティーが表示されれば合格です。

Keyboard test Press any key

KEY VELO C#2 64

When it is inoperative:

Refer to [2] 2, [3] 1 and 6, and [4] 2 in the Troubleshooting section (p.34-40).

NGの場合・

トラブルシューティングの【2】の2、【3】の1、6及び【4】 の2を参照して下さい(P.34~40)。

[12] MIDI Test

- 1. Press [NUMBER 4] while holding down [EXIT].
- Connect a single cable to both the MIDI IN and the MIDI OUT connectors on the rear panel.
- 3. Check that the "OK" message is displayed.
- 4. Disconnect the cable and check that the display changes from "OK" to "NG."

【12】MIDI テスト

- 1. [EXIT] を押しながら [NUMBER4] を押します。
- 2. 本体リアパネルの MIDI IN と MIDI OUT を一本のケーブルでつなぎます。
- 3. "OK"の表示が出ることを確認して下さい。
- 4.ケーブルを抜き、表示がNGに変わることを確認して下さい。

MIDI test Connect MIDI cable

connection [OK]

When it is inoperative:

Refer to [4] in the Troubleshooting section (p.40).

NGの場合:

トラブルシューティングの【4】を参照して下さい (P.40)。

[13] Output Test

- 1.Connect the cable to each MIX OUT L/R and DIR OUT L/R jacks on the rear panel, and observe each signal by an instrument such as an oscilloscope.
- 2. Press [NUMBER 5] while holding down [EXIT].
- 3. Confirm that the voice is output only through MIX OUT L.

4. Press [CURSOR R].

5. Check that the voice is output only through MIX OUT R.

6. Press [CURSOR R].

7.Check that the voice is output only through DIR OUT L.

8. Press [CURSOR R].

9. Check that the voice is output only through DIR OUT R.

【13】出力テスト

- 1.本体リアパネルのMIX OUT L/RとDIR OUT L/Rにそれぞれ 音声ケーブルをつなぎ、それぞれの信号をオシロスコープなどで 観測できるようにして下さい。
- 2. [EXIT] を押しながら [NUMBER5] を押します。
- 3. MIX OUT Lだけから音声が出力されていることを確認して下さい。
- 4. [CURSOR R] を押します。
- 5. MIX OUT Rだけから音声が出力されていることを確認して下さい。
- 6. [CURSOR R] を押します。
- 7. DIR OUT Lだけから音声が出力されていることを確認して下さい。
- 8. [CURSOR R] を押します。
- 9. DIR OUT Rだけから音声が出力されていることを確認して下さい。

Output test Select CH with CURSOR

outrut

[MIX-L]

When it is inoperative:

Refer to [3] 1 and 8 in the Troubleshooting section (p.38, 39).

NG の場合:

トラブルシューティングの【3】の1、8を参照して下さい (P.38, 39)。

[14] Effect Test

- 1. Press [NUMBER 6] while holding down [EXIT].
- Hold down any key on the keyboard for approximately one second.
- If the sound comes out clearly, the test has been successfully completed. (Make sure that noise is not mixed with the sound.)

【14】エフェクト・テスト

- [EXIT] を押しながら [NUMBER6] を押します。
 仕意の鍵盤を約一秒押えます。
- 3. 音がきれいに鳴れば合格です (ノイズが混ざっていないこと)。

Effect test Press any key Is sound clear?

When it is inoperative:

Refer to [3] 1, 3 and 4 in the Troubleshooting section (p.38, 39).

NG の場合:

トラブルシューティングの【3】の1、3、4を参照して下さい (P.38, 39)。

[15] D/A Adjustment

- 1. Use an instrument such as an oscilloscope to observe the output waveform of MIX OUT L on the rear panel.
- 2. Press [NUMBER 7] while holding down [EXIT].
- 3. A sine wave with a relatively low sound volume should be output. Make it a smooth sine wave by adjusting VR1 on the Jack Board.

【15】D/A調整

- 1.本体リアパネルのMIX OUT Lの出力波形をオシロスコープなどで観測できるようにします。
- 2. [EXIT] を押しながら [NUMBER7] を押します。
- 3. 微小音量の正弦波が出力されるので、波形が滑らかな正弦波になるように、ジャックボードのVR1を調整して下さい。

D/A adjustment Move VR on jack board

Is sound clear?

[16] Exit Test Mode

1. Press [NUMBER 8] while holding down [EXIT]. 2. Press [INC/YES] when the display below is shown.

【16】テストモードから抜ける

1. [EXIT] を押しながら [NUMBER8] を押します。 2. 下のように表示されたら、[INC/YES] を押します。

Exit test mode

?[Y/N]

NOTE : ____

If operation does not leave the test mode even when the above steps are performed, turn the power switch off briefly, then back on. This returns operation to the Multi mode.

_ 注意:

上記の操作をしてもテストモードから抜けられない場合は、一旦電源スイッチをoffにして下さい。再び電源スイッチをonにすると、マルチモードに戻ります。

TROUBLESHOOTING

When the unit is damaged or out of order for some reason, check the following items while referring to the circuit diagrams.

- · Is the voltage supplied to the ICs correct?
- · Is the clock being output?
- · Are signals being output?

_ NOTE : ___

There are cases in which the unit, though operating correctly, may seem damaged or out of order because of incorrect parameter settings or problems with peripheral equipment.

不良の場合、回路図を参照して下記の事を確認して下さい。

トラブルシューティング

- IC等の供給電源は正常か?
- クロックは来ているか?
- 信号は来ているか?

注意: _

本体が正常に動作している場合でも、パラメータの設定や周辺 機器の状態等により不良に見えることがあります。

MB → Main Board

JB → Jack Board CB → Card Board

BB → Bender Board

PSB → Power Supply Board

VLB → Volume L Board

VRB → volume R Board

[1] Power-related Malfunctions

1. Power is Interrupted

· Is AC voltage being conducted on the (first order side ??) of the power transformer?

If not:

Check the AC cord, power switch, line bypass condenser, etc.

· Is the voltage on the second order side sufficient?

If not:

Check the power transformer, power switch, C1—C6. C10, C12, C16, D1, D2, IC2-4 (on the PSB), etc.

• Is +5V coming to the TP4 (on the MB)?

If not:

Check IC1, IC2, C8, C9 and D3 (on the PSB), Check that there is no short between the power supply patterns on the Main Board, Jack Board and Card Board

HOW TO CHECK FOR SHORT CIRCUITS AMONG THE POWER SUPPLY PATTERNS

First, disconnect all of CN1-3 (on the PSB). Make sure at this time that +5V is being conducted over pin three of IC2. Then, one by one, reconnect the connectors that you just unplugged to find which connector decreases the voltage of pin three on IC2 to a point as low as OV. If the voltage decreases when CN1 is reconnected, the power supply pattern on the jack board has a short circuit. If the voltage decreases when CN2 is reconnected, the power supply pattern on either the Main Board or Card Board has a short circuit. If the voltage decreases when CN3 is reconnected, the power supply pattern on the Main Board has a short circuit. Remember that CN2 and CN3 have separate power supplies on the Main Board.

【1】 雷源関係の不良

1. 電源が入らない

・電源トランスの1次側AC電圧が来ていますか。

NG の場合:

ACコード、パワースイッチ、ラインバイパスコンデンサ等 をチェックして下さい。

・電源トランスの2次側電圧は十分ですか。

NGの場合:

電源トランス、パワースイッチ、C1~C6、C10、C12及び C16、D1、D2、IC2~4 (on PSB) 等をチェックして下さい。

• TP4 (on MB) に+5Vが来ていますか。

NG の場合:

IC1、IC2、C8.C9及びD3 (on PSB) をチェックして下さ い。また、メインボード、ジャックボード、カードボード の各ボード上で電源パターン間にショートがないかチェッ クして下さい。

電源パターン間のショートの有無を調べる方法

まず最初にCN1~3 (on PSB) をすべて抜いて下さい。この時 IC2の3番ピンに+5Vが出ていることを確認して下さい。次に、 抜いたコネクタを再び一本づつ接続していき、IC2の3番ピンの 電圧がOV近くまで低下するコネクタを調べます。CN1を接続 した時に電圧の低下が起これば、ジャックボードの電源パター ンがショートしています。CN2を接続したときに電圧の低下が 起これば、メインボードまたはカードボード上で電源パターン がショートしています。CN3を接続したときに電圧の低下が起 これば、メインボード上の電源パターンがショートしています。 なお、CN2とCN3は、メインボード上では別系統の電源になっ ていますので注意して下さい。

2. Reset is Activated

- · Go through all the check points of the above section. "1. Power is Interrupted."
- · Is IC2 extraordinarily hot? Is the voltage of pin three on IC2 (on the PSB) less than +4.25V?

If so:

Check each power supply pattern of the Main Board. Jack Board, Card Board and Power Supply Board. Check also all the elements that are connected to the +5V power supply.

When the electric current which is conducted through IC2 becomes greater than 1A because of the abnormality of the power supply pattern, IC2 becomes heated and also the output voltage of IC2 decreases. When the output voltage decreases to lower than + 4.25V, the reset IC (IC1) functions and reset is activated.

3. Low Internal Battery Power

• Is more than + 2.7V being conducted to TP5 (on the MB) when the power is turned off?

If not ·

Exchange the batteries on the Main Board with new ones. If the problem persists after changing the batteries, check R44-49, Q7, Q8, D2, IC34 (on the MB) and their peripheral patterns. Also check that there are no short circuits among other patterns connected to the + terminal of the batteries.

• Is more than + 2.7V being conducted to pin number 52 on IC36 (on the MB) when the power is on?

If not:

Check R49, IC34 (on the MB) and their peripheral patterns. Then, check the pattern between pin number 7 on IC34 and pin number 52 on IC36. Also check that there is no short circuit between pin number 52 on IC36 and other pins.

BATTERY ERROR MESSAGE

The installed batteries and the batteries for the DATA card are monitored as to whether they have sufficient voltage or not by the voltage which is conducted to pin number 52 (installed batteries) and pin number 53 (card batteries) on IC36 (on the MB). Battery power is sufficient if the voltage is more than + 2.7V and less than + 3.5V; error messages are shown when the voltage is not within that range.

2.リセットがかかる

- ・「1.電源が入らない」に記されているチェックを一通り行って
- ・IC2が異常に熱くなっていませんか。また、IC2 (on PSB) の 3番ピンの電圧が+4.25V以上ありますか。

NGの場合:

メインボード、ジャックボード、カードボード、電源ボー ドの各ボード上の電源パターンをチェックして下さい。ま た、+5V電源に接続されている全ての素子をチェックして 下さい。

電源パターンの異常等が原因となって、1Aを超える電流がIC2 に流れると、IC2 は発熱し、同時にIC2の出力電圧が低下しま す。出力電圧が+4.25V以下になると、リセットIC (IC1) が動 作してリセットがかかります。

3.Int. Batt.が "Low" と表示される

・電源 off 時に、TP5 (on MB) に + 2.7V 以上の電圧が出てい ますか。

NGの場合:

メインボード上のバッテリーを新しいものと交換して下さ い。それでも直らない場合は、R44~49、Q7、Q8、D2、 IC34 (on MB) とそれらの周辺のパターンをチェックして 下さい。また、バッテリーの+端子につながるパターンが 他の場所にショートしていないかチェックして下さい。

・電源 on 時に、IC36 (on MB) の52番ピンに + 2.7V以上の電 圧が来ていますか。

NGの場合:

R49、IC34 (on MB) とそれらの周辺のパターンをチェッ クして下さい。次に、IC34の7番ピンとIC36の52番ピン との間のパターンをチェックして下さい。また、IC36の52 番ピンが他のピンとショートしていないかチェックして下 さい。

バッテリーのエラーメッセージについて

内蔵バッテリー及びDATA カードのバッテリーは、それぞれ IC36 (on MB) の52番ピン及び53番ピンに入力される電圧に よって、正常であるかどうかがチェックされています。電圧が +2.7V以上+3.5V以下であれば正常と判断され、それ以外なら ばエラーメッセージが表示されます。

[2] Operation System Malfunctions

- 1.DATA card is incorrect. (See [2] in the TEST MODE section, p.30.)
- a) Patches of the card cannot be read or written correctly.
- First confirm that all the switches of [INT/CARD], [WRITE] and [INC/YES] function properly. (See [5] in the TEST MODE section, p.31.) If everything works properly, check IC28 (on the MB). Also check CN14 (on the MB). It is possible that the DATA card itself has some sort of malfunction.
- b) Display shows "DATA card battery low".
- The battery in the DATA card is worn out. Replace it with a new one.
- Check CN14 (on the MB). Check R51, IC34 (on the MB) and their peripheral patterns. Then check the patterns between pin number 7 on IC34 and pin number 52 on IC36. Also check that there is no short circuit between pin number 52 on IC36 and other pins. It is also possible that the batteries of the DATA cards themselves are low.
- · Refer to [1] 3. "Low Internal Battery Power."
- 2. WAVEFORM card is incorrect. (Refer to [4] in the TEST MODE section, p.30.)
- a) Display shows "WAVEFORM card is not ready".
- Does pin number 5 on CN12 (on the MB) reach High level when the WAVEFORM card is inserted?

If so:

Check the wiring between the following: R1, CN1, CN3 and CN3 (on the CB) and the Main Board. Check also R56, D3, IC37 (on the MB) and the patterns which are connected to them. It is also possible that WAVEFORM card itself has some sort of malfunction.

 Does a pulse wave appear at pin number 11 on IC37 when the WAVEFORM card is inserted?

When there is no pulse wave:

Check IC37, D4, RA3, CN3 and CN4 (on the MB). Confirm that pin number 28 is connected to IC5 (on the MB). Referring to the circuit diagrams, check all the switches and diodes, which are connected to the pin number 28 on IC5, on the all the boards except the main board.

- b) The display of the WAVE NAME is incorrect.
- Does it sound correct when the WAVE in the WAVEFORM card is selected?

When it sounds correct:

Check IC13 (on the MB) and its peripheral. Check CN9 (on the MB) and the wirings which are connected to CN9. Also check the LCD unit.

If not:

Check CN1 to CN3 (on the CB). Check the wiring which connects the card board to the main board. Check also IC24 (on the MB) and its peripheral. It is also possible that the WAVEFORM card itself has some sort of malfunction.

【2】操作系の不良

- 1.DATA カードがおかしい (テストモードの【2】(P.30) を参照して下さい。)
- a) カードのパッチの内容が正しくリード・ライトできない。
- ・まず、[INT/CARD] [WRITE] 及び [INC/YES] のスイッチがすべて正常に動作することを確認して下さい (テストモードの【5】(P.31) を参照のこと)。異常がなければ、次にIC28 (on MB) をチェックして下さい。また、CN14 (on MB) をチェックして下さい。なお、DATAカード自体の不良が原因となる場合もあります。
- b) "DATA card battery low" と表示される。
- DATAカードのバッテリーが消耗していると考えられます。 バッテリーを新しいものに交換して下さい。
- ・CN14 (on MB) をチェックして下さい。R51、IC34 (on MB) とそれらの周辺のパターンをチェックして下さい。次に、IC34 の7番ピンとIC36の52番ピンとの間のパターンをチェックして下さい。また、IC36の52番ピンが他のピンとショートしていないかチェックして下さい。なお、DATAカードのバッテリー自体が消耗している場合もあります。
- 【1】の3.「Int. Batt.が "Low" と表示される」を参考にして下さい。
- 2. WAVEFORM カードがおかしい (テストモードの【4】(P.30) を 参昭して下さい。)
- a) "WAVEFORM card is not ready" と表示される。
- WAVEFORMカードを挿入したときに、CN12 (on MB) の5 番ピンが High レベルになりますか。

NGの場合:

R1、CN1、CN3およびCN3 (on CB) とメインボード間の ワイヤリングをチェックして下さい。また、R56、D3、IC37 (on MB) 及びそれらに接続されているパターンを チェックして下さい。なお、WAVEFORMカード自体の不良が原因の場合もあります。

・WAVEFORMカードを挿入したときに、IC37 (on MB) の11 番ピンにパルス波形が出ますか。

出ない場合:

IC37、D4、RA3、CN3、CN4 (on MB) をチェックして下さい。IC5 (on MB) の28番ピンがD4に接続していることを確認して下さい。また、回路図を参照して、IC5の28番ピンに接続されている、メインボード以外の全てのボード上の全てのスイッチ及びダイオードをチェックして下さい。

- b) WAVE NAMEの表示がおかしい。
- WAVEFORMカード内のWAVEを選んだ時に、音は正常に出ますか。

正常な場合:

IC13 (on MB) 及びその周辺をチェックして下さい。CN9 (on MB) と、そこに接続されているワイヤリングをチェックして下さい。また、LCD ユニットをチェックして下さい。

NG の場合:

CN1~CN3 (on CB) をチェックして下さい。カードボードとメインボードを接続しているワイヤリングをチェックして下さい。また、IC24 (on MB) 及びその周辺をチェックして下さい。なお、WAVEFORMカード自体の不良が原因の場合もあります。

3. Patch is written but not memorized.

- Confirm that the [WRITE] and [INC/YES] buttons function correctly, referring to [5] in the TEST MODE section, p.31.
- Check IC29, IC30 (on the MB) and their peripherals.
 Also check D2, Q8 (on the MB) and their peripherals.

4.Button switch is out of order. (See [5] in the TEST MODE section, p.31.)

- Check the switches which are out of order and the diodes which are close to these switches. Referring to the circuit diagrams, check the patterns of the scan lines which are connected to those switches on all the boards.
- Check CN3, CN4 (on the MB) and the wirings which are connected to CN3 and CN4. Check the wirings and connectors on all the boards attached to the panel.
- Is a pulse waveform coming from all the pins of pin numbers 48 to 55 on IC5 (on the MB)?

When there are some pins from which a pulse waveform cannot be detected:

IC5 is defective.

When a pulse waveform is not coming from any of those pins:

IC5 is out of order. Check the following points.

 Is a pulse waveform coming from pin number 46 on IC5?

If not:

IC5 is out of order. Check for short circuits among the pins on IC5, short circuits in the peripheral patterns, and the cut-off of the patterns. Then check the following matters.

• Is a clock signal coming to pin number 3 on IC5?

When it is inoperative:

Check IC36, FL28, R52 (on the MB) and their peripheral patterns.

• Is a clock signal coming to pin number 2 on IC5?

When it is inoperative:

Check IC7 (on the MB) and its peripheral patterns.

Switches, encoders, sliders and LEDs are periodically scanned by IC5 (on the MB), and reading in and lighting up are executed. The pulse waveform which appears at pin number 46 on IC5 indicates that this scanning is accomplished correctly. When scanning is stopped because of an insufficient level of the clock signal is supplied to IC5, or because IC5 itself is defective, the pulse waveform is not output. In such cases, problems will appear in reading data from sliders and encoders, and lighting up of the LEDs.

3. パッチをライトしても記憶されない

- ・テストモードの【5】(P.31) を参照して、[WRITE] 及び [INC/YES] のボタンが正常に動作することを確認して下さい。
- IC29及びIC30 (on MB) とそれらの周辺をチェックして下さい。また、D2、Q8 (on MB) とそれらの周辺をチェックして下さい。

4.ボタン・スイッチがおかしい (テストモードの【5】(P.31) を参 照して下さい。)

- ・不良症状を起こしたスイッチと、そのスイッチのそばにあるダイオードをチェックして下さい。また、回路図を参照して、そのスイッチにつながるスキャン線のパターンを、全てのボードについてチェックして下さい。
- ・CN3及びCN4 (on MB) と、それらに接続されているワイヤリングをチェックして下さい。また、パネルに取り付けられている全てのボードについて、ワイヤリングとコネクタの接続をチェックして下さい。
- IC5 (on MB) の48番ピンから55番ピンにかけて、全てのピンからパルス状の波形が出ていますか。

出ているピンと出ていないピンがある場合:

IC5の不良が考えられます。

どのピンからも出ていない場合:

IC5が動作していません。以下のチェックを行って下さい。

・ IC5 の 46 番ピンにパルス状の波形が出ていますか。

NGの場合:

IC5が動作していません。IC5のピン間ショートや周辺パターンのショート、パターン切れ等をチェックし、以下のチェックを行って下さい。

• IC5の3番ピンにクロックが来ていますか。

NG の場合:

IC36、FL28及びR52 (on MB) とそれらの周辺のパターンをチェックして下さい。

・ IC5の2番ピンにクロックが来ていますか。

NG の場合:

IC7 (on MB) とその周辺のパターンをチェックして下さい。

パネル上のスイッチ、エンコーダー、スライダー及び LED は、IC5 (on MB) によって周期的にスキャンされ、読み込みや点灯が行われています。IC5の46番ピンに現れるパルス状の波形は、このスキャンニングが正常に行われている事を示しています。IC5に十分なレベルのクロックが供給されなかったり、IC5自体の不良によってスキャンニングが停止すると、パルス波形は出力されません。

この場合にはスライダー、エンコーダーの読み込みやLEDの点灯にも不良症状が現れます。

- **5.LED is incorrect**. (Refer to **[6]** in the TEST MODE section, p.31.)
- Check the LEDs which are malfunctioning. Check all the patterns of scan lines which are connected to these LEDs on all the boards.
- Check CN3, CN4 (on the MB) and the wirings which are connected to them. Also check the wirings and connectors on all the boards installed to the panel.
- · Check IC2, IC3 (on the MB) and their peripheral patterns.
- Check IC5 (on the MB), as in "4. Button switch is out of order," above.
- **6. Slider is out of order.** (Refer to [7] in the TEST MODE section, p.31.)
- a) Display does not change when slider is moved.
- Check that the output terminal voltage of the slider changes between 0—+5V when the slider is moved.
- Check the 4051 to which the slider with the problem is connected, referring to the circuit diagrams. Also check the op-amp (operation amplifier) which is connected to the output of the 4051.
- Check CN1 to CN4 (on the MB). Also check the connected wirings.
- Check the operation of IC5 (on the MB), as in "4. Button switch is out of order." above.
- b) Parameter value doesn't change continuously.
- There is a possibility that the notches is produced in the slider. Replace the slider with a new one.

When the outputs of several sliders have short circuits, several parameters may simultaneously change by moving a single slider. In such a case, the display is unstable and the value seems to change irregularly. Refer to the next item c) for this problem.

- c) Display changes irregularly.
- Referring to the circuit diagrams, check that there is no short circuit between output of the slider with the problem and the output of another slider.
- Check DA1, DA2, CA1, RA5, RA6 (on the MB) and their peripherals. Also check that there is no short circuit among the pins numbered 30—37 on IC5 (on the MB).
- Check that there is more than $\pm\,7V$ power voltage for the 4051 which is connected to the slider with the problem. Check that the input pin of the 4051 is not open.
- When the power voltage is less than $\pm 7 \text{V}$:
 - The power supply used for the 4051 is from the op-amp, which decreases the \pm 15V by half. Referring to the circuit diagrams, check the op-amp that supplies the power supply voltage and its peripheral elements and patterns.
- Check that normal multiplex signals are input in pin numbers 9—11 of the 4051.

- 5.LEDがおかしい (テストモードーの【6】(P.31) を参照して下さい。)
- ・不良症状を起こしたLEDをチェックして下さい。また、回路 図を参照して、そのLEDにつながるスキャン線のパターンを、 全てのボードについてチェックして下さい。
- ・CN3及びCN4 (on MB) と、それらに接続されているワイヤリングをチェックして下さい。また、パネルに取り付けられている全てのボードについて、ワイヤリングとコネクタの接続をチェックして下さい。
- ・IC2及びIC3 (on MB) とそれらの周辺のパターンをチェック して下さい。
- ・以下、「4.ボタン・スイッチがおかしい」と同様に、IC5 (on MB) のチェックを進めて下さい。
- 6.スライダーがおかしい (テストモードの【7】(P.31) を参照して下さい。)
- a) スライダーを動かしても表示が変わらない。
- ・スライダーを動かした時に、スライダーの出力端子電圧が0~ +5Vに変化することを確認して下さい。
- ・回路図を参照して、不良の発生したスライダーがつながっている4051をチェックして下さい。また、その4051の出力につながっているオペアンプをチェックして下さい。
- CN1~CN4 (on MB) をチェックして下さい。また、それら に接続されているワイヤリングをチェックして下さい。
- ・「4.ボタン・スイッチがおかしい」と同様に、IC5 (on MB) の 動作をチェックして下さい。
- b) パラメータの数値が連続的に変化しない。
- ・スライダーにがりが発生している恐れがあります。スライ ダーを新しいものと交換して下さい。

複数のスライダーの出力がショートしている場合、一方のスライダーを動かすと、複数のパラメーターが同時に変化することになります。この時、表示がぱらぱらと乱れ、数値が不連続に変化しているように見えることもあります。これについては、次項c)を参照して下さい。

- c) スライダーを動かすと、表示がちらちらまたたくように変化 する。
- 回路図を参照しながら、不良の発生するスライダーの出力が他のスライダーの出力とショートしていないかチェックして下さい。
- ・DA1、DA2、CA1、RA5及びRA6 (on MB) とそれらの周辺をチェックして下さい。また、IC5 (on MB) の $30\sim37$ 番ピンについて、ピン間のショートがないかどうかをチェックして下さい。
- ・不良の発生するスライダーに接続されている4051について、 電源電圧が±7V以上あるかチェックして下さい。また、その 4051の入力ピンがオープンになっていないかチェックして下 さい。

電源電圧が±7V以下の場合:

- 4051の電源はオペアンプによって±15V電源を約半分におとしたものを使用しています。回路図を参照して、電源電圧を作っているオペアンプと、その周辺の素子及びパターンのチェックを行って下さい。
- 4051の9~11番ピンに正常なマルチプレクス信号が入力されているかチェックして下さい。

The output of 8 sliders are input to one 4051. The 4051 multiplexes them and outputs them. When the power supply voltage greatly decreases, crosstalk is caused among the inputs of the 8 sliders of the 4051, and one input can effect other inputs. Also when there are some open inputs among the inputs of the 4051, these inputs will be affected by other inputs.

- d) Parameter value changes even when the slider is not moved.
- Check CN1—CN4 (on the MB), and the wirings which are connected to them. Check also the connections of these wirings on the Volume_L and Volume_R boards.
- Check DA1, DA2, CA1, RA5, RA6 (on the MB) and their peripherals
- Check that the multiplex waveform is input in all the pins of the number 30—37 on IC5 (on the MB).
- **7.Encoder is out of order**. (Refer to [8] in the TEST MODE section, p.31.)
- · Check the rotary encoder and its peripheral.
- Check CN1, CN4 (on the MB) and the wirings which are connected to them. Check also the connections of these wirings on the Volume L board.
- Check CN7 (on the VLB) and the wirings which are connected to it.
- Check IC6, C6, C7, RA7 (on the MB) and their peripherals.

The output of the encoder is sent through a low pass filter which consists of RA7, C6 and C7 (on the MB). This is to prevent jumps in value when the encoder is rotated slowly. When the values of C6, C7 or RA7 are greatly different from that of the circuit diagrams because of errors or defects, jumps in value and operation defects can be caused.

8. Malfunctions of the bender, modulation or after touch. (Refer to [9] in the TEST MODE section, p.31.)

Check the following items in all cases from a) to g) below.

- Check the connection between the Bender Unit and Jack Board. Check the connection between CN2 (on the JB) and CN5 (on the MB).
- Check the connection between the Keyboard and Main Board.
- Confirm that a standard voltage of + 5V is being conducted to pin number 1 on CN5 (on the MB). If the standard voltage is wrong, check the pattern of the standard voltage and all the connected elements, referring to the circuit diagrams.
- Check IC4, IC9, RA6, DA1, DA2, CA1 (on the MB) and their peripherals. Also check that there is no short circuit, a loose pin or pattern cutoff for pin number 30 on IC5.

1個の4051の入力には8本分のスライダーの出力が接続され、4051はこれらをマルチプレクスして出力しています。電源電圧が大きく低下すると、4051の8本の入力間にはクロストークが発生し、一つの入力が他の入力に影響を与えることになります。また、4051の入力のうち、オープンになったままのものがあると、その入力は他の入力によって影響を受けます。

- d) スライダーを動かさないのにパラメータの数値が変化する。
- CN1~CN4 (on MB) 及びそれらに接続されているワイヤリングをチェックして下さい。また、Volume_L及びVolume_ Rボード上でのそれらのワイヤリングの接続ををチェックして下さい。
- DA1、DA2、CA1、RA5及びRA6 (on MB) とそれらの周辺 をチェックして下さい。
- IC5 (on MB) の30~37番ピンについて、全てのピンにマルチプレクス波形が入力されているかチェックして下さい。また、マルチプレクス波形にノイズが乗っていないかチェックして下さい。
- 7.エンコーダーがおかしい (テストモードの【8】(P.31) を参照して下さい。)
 - ロータリーエンコーダーとその周辺をチェックして下さい。
- CN1及びCN4 (on MB) と、それらに接続されているワイヤリングをチェックして下さい。また、Volume_Lボード上でのそれらのワイヤリングの接続をチェックして下さい。
- CN7 (on VLB) と、それに接続されているワイヤリングを f_{xy} クして下さい。
- IC6、C6、C7及びRA7 (on MB) とそれらの周辺をチェックして下さい。

エンコーダーの出力は、RA7とC6及びC7 (on MB) によって 構成されるローパスフィルターを通ります。これは、エンコー ダーをゆっくり回転させた場合の値のとびを防ぐためのもので す。万一、C6、C7またはRA7の値が誤差や不良等によって回路 図の値と大きく異なっていた場合、値のとびや動作不良が発生します。

8. ベンダー・モジュレーション・アフタータッチの不良(テストモードの【9】(P.31)を参照して下さい。)

以下、a)~g)の全ての場合において:

- ・ ベンダーユニットとジャックボード間の接続をチェックして下さい。また、CN2 (on JB) と CN5 (on MB) の間の接続をチェックして下さい。
- ・ 鍵盤とメインボード間の接続をチェックして下さい。
- ・ CN5 (on MB) の1番ピンに+5Vの基準電圧が出ていることを確認して下さい。
- 基準電圧がおかしい場合には、回路図を参照して、基準電圧のパターン及び、接続されている全ての素子をチェックして下さい。
- IC4、IC9、RA6、DA1、DA2、CA1 (on MB) とそれらの周 辺をチェックして下さい。また、IC5の30番ピンについて、 ショートや足浮き・パターン切れがないかどうかチェックして 下さい。

- a) Bender doesn't move up or down all the way.
- Does the voltage on pin number 3 on CN5 (on the JB) reach + 5V when the bender is moved to the right?

If not:

Check the pattern between CN2 and CN4 (on the JB). It is also possible that bender unit is defective.

If so:

Check IC9b, Q3, R13, R14, R22 and R23 (on the MB). When the gain of IC9 is not enough, or when the voltage decrease of emitter follower of Q3 is large, the bender voltage will not increase as high as \pm 5V.

- b) Bender doesn't go down.
- Is the +5V pulse waveform coming from pin number 4 on CN5 (on the MB)?

If not:

Check Q4 and pin number 45 on IC5 (on the MB). When the pulse waveform is not coming from pin number 45 on IC5, the operation of IC5 is possibly defective. Check the operation of IC5, referring to "4. Button switch is out of order".

If so:

Check R13, R14, R22, R23 and Q3 (on the MB). Besides these, there is a possibility of a defect of IC5.

- It is also possible that the bender unit is defective.
- Bender is active even though the bender is set to the center position.
- Is the voltage of pin number 3 on CN5 (on the MB) at 0V, when the bender is set to the center?

If not:

Check the bender unit. Also check the connection from the bender unit to the Jack Board.

If so:

Check Q3, IC9 (on the MB) and their peripherals. When it is operating properly, setting the bender to the center causes the voltage on pin number 7 on IC9, pin number 1 on Q3 and pin number 13 on IC4 to reach OV.

d) Modulation is either difficult to activate, or is never on.
Does the voltage at pin number 2 on CN5 on the Main Board reach +5V when the bender lever is pushed up?

If not:

Check IC8 (on the JB) and its peripheral elements and patterns. It is also possible that the bender unit itself is defective.

If so:

Check Q1, R9 and R10 (on the MB).

- a) ベンダーが上がり(下がり)切らない。
- ベンダーを右に倒すと、CN5 (on MB) の3番ピンの電圧が+
 5V になりますか。

NGの場合:

CN2とCN4 (on JB) の間のパターンをチェックして下さい。また、ベンダーユニットの不良も考えられます。

OK の場合:

IC9b、Q3、R13、R14、R22及びR23 (on MB) をチェックして下さい。IC9のゲインが不足したり、Q3のエミッタ・フォロワでの電圧降下が大きいと、ベンダー電圧が+5Vに上がり切らなくなります。

- b) ベンダーが下がらない。
- CN5 (on MB) の4番ピンに、+5Vのパルス波形が出ていますか。

NG の場合:

Q4及びIC5 (on MB) の45番ピンをチェックして下さい。 IC5の45番ピンからパルス波形が出ていない場合には、IC5 の動作不良が考えられます。「4.ボタン・スイッチがおかしい」を参照の上、IC5の動作をチェックして下さい。

OK の場合:

R13、R14、R22、R23、Q3 (on MB) をチェックして下 さい。その他、IC5の不良等が考えられます。

- ・ベンダー・ユニットの不良の可能性もあります。
- c) ベンダーを中央にしてもベンダーがかかりっ放しになっている。
- ベンダーを中央にした状態で、CN5 (on MB) の3番ピンが0V になっていますか。

NG の場合:

ベンダー・ユニットをチェックして下さい。また、ベン ダー・ユニットからジャックボードへの接続をチェックし て下さい。

OK の場合:

Q3、IC9 (on MB) とそれらの周辺をチェックして下さい。 正常な状態では、ベンダーを中央にすると、IC9の7番ピン、 Q3の1番ピン及びIC4の13番ピンは全て0Vになります。

- d) モジュレーションが効きにくいか、もしくは効かない。
- ベンダーレバーを上方へ押し込んだ時、メインボード上CN5の2番ピンが+5Vになりますか。

NG の場合:

IC8 (on JB) とその周辺の素子及びパターンをチェックして下さい。また、ベンダーユニットの不良も考えられます。

OK の場合:

Q1、R9及びR10 (on MB) をチェックして下さい。

- e) Modulation is continuously active.
- Is the voltage of pin number 2 at 0V when the bender lever is released?

If not:

Check the bender unit. Also check the connection from the bender unit to the Jack Board.

If so:

Check Q1 (on the MB) and its peripherals. When it is operating properly, releasing the bender causes the voltage at pin number 1 on Q1 and pin number 15 on IC4 to reach OV.

- f) After touch is either difficult to activate, or is never
- Check CN7 (on the MB) and the cable which is connected to it. Also check the connectors on the Keyboard and their peripherals.
- Does the voltage of pin number 14 on IC4 (on the MB) reach + 5V when the keys are pressed down?

If not:

Referring to the circuit diagrams, check IC10 (on the MB) and its peripheral elements and patterns. Also check R11, R12 and Q2 (on the MB).

If so:

IC5 (on the MB) may be defective.

- g) After touch is continuously active.
- Is the voltage at pin number 1 on IC10 (on the MB) less than OV when a key is released?

If not:

Check the connections from the sensor of the after touch to the Main Board. Check also IC10 (on the MB) and its peripherals.

If so:

Check Q2 (on the MB) and its peripherals. When it is operating properly, releasing a key causes the voltage at pin number 1 on Q2 and pin number 14 on IC4 (on the MB) to become 0V.

- e) モジュレーションがかかりっ放しになる。
- ベンダーレバーから手を放した状態で、CN5 (on MB) の2番ピンが0Vになりますか。

NG の場合・

ベンダー・ユニットをチェックして下さい。また、ベン ダー・ユニットからジャックボードへの接続をチェックし て下さい。

OK の場合:

Q1 (on MB) とそれらの周辺をチェックして下さい。正常な状態では、ベンダーを放すと、Q1の1番ピン及びIC4の15番ピンはどちらも0Vになります。

f)アフタータッチが効きにくいか、もしくは効かない。

- CN7 (on MB) と、それに接続されているケーブルをチェックして下さい。また、その先に接続されている、キーボード上のコネクター及びその周辺をチェックして下さい。
- 鍵盤を押し込んだ時、IC4 (on MB) の14番ピンの電圧が+5V になりますか。

NG の場合:

回路図を参照して、IC10 (on MB) とその周辺の素子及びパターンをチェックして下さい。また、R11、R12及びQ2 (on MB) をチェックして下さい。

OK の場合:

IC5 (on MB) の不良等が考えられます。

- g) アフタータッチがかかりっ放しになる。
- ・ 鍵盤から手を放した状態で、IC10 (on MB) の1番ピンが0V 以下になっていますか。

NG の場合:

アフタータッチのセンサーからメインボードに至るまでの 接続をチェックして下さい。また、IC10 (on MB) とその 周辺をチェックして下さい。

OK の場合:

. Q2 (on MB) とその周辺をチェックして下さい。正常な状態では、鍵盤から手を放すと、Q2の1番ピン及びIC4 (on MB) の14番ピンはどちらもQ200 の14番ピンはどちらもQ20 の1番ピンなびIC4 (on MB) の14番ピンはどちらもQ20 の1番ピンなどものいたなります。

- **9.Pedal Malfunctions** (Refer to [10] in the TEST MODE section, p.31.)
 - · Check the following items for both a) and b):
- Check the connection between CN5 (on the JB) and CN10 (on the MB).
- Referring to the circuit diagrams, check that the standard voltage is + 5V.
- a) EXT. Pedal malfunctions.
- Does the voltage at pin number 2 on CN10 (on the MB) become +5V when the EXT. Pedal is pressed all the way down or when the Pedal is pulled out?

If not:

Check IC8a, JK6 (on the JB) and their peripheral elements and patterns. Also check D1, D2 and FL10 (on the JB). It is also possible that the EXT. Pedal itself is defective

If so:

Check R15, IC4, IC9, RA6, DA1, DA2, CA1 (on the MB) and their peripheral patterns. Also check pin number 30 on IC5 (on the MB) for a short circuit, loose pin or pattern cutoff. When nothing is found wrong, it is possible that IC5 itself is defective.

- b) HOLD Pedal doesn't function.
- Is a pulse waveform coming from pin number 2 on IC12 (on the MB)?

When it is inoperative:

Check IC11 (on the MB) for short circuits among the pins, loose pin or pattern cutoff. It is also possible that IC11 or IC12 themselves are defective.

 Does the voltage at pin number 1 on CN10 (on the MB) become 0V when the HOLD Pedal is pressed down? Also, does the voltage at pin number 1 on CN10 become +5V when the HOLD Pedal is released?

If not:

Referring to the circuit diagrams, check the patterns from JK7 to Q7 (on the JB) and the elements connected to these patterns. Also check FL11 (on the JB). It is also possible that the JK7 is not connected properly or the HOLD Pedal itself is defective.

If so:

Check IC11, IC12, R29 (on the MB) and their peripheral patterns.

When HOLD is on, the electric potential of pin number 3 on Q7 (on the JB) reaches High level, and pin number 1 on IC12 (on the MB) reaches Low level, and a pulse waveform is output from pin number 3 on IC12. When HOLD is off, the electric potential of pin number 3 on Q7 reaches Low level, and pin number 1 on IC12 (on the MB) reaches High level, and pin number 3 on IC12 reaches High level.

9.ペダル類の不良 (テストモードの【10】(P.31) を参照して下さい。)

以下、a)、b) において:

- CN5 (on JB) と CN10 (on MB) の間の接続をチェックして下さい。
- 回路図を参照の上、基準電圧が+5Vあるかどうかをチェックして下さい。
- a) EXT.Pedalがおかしい。
- EXT.Pedalを一杯に踏み込んだ時及びEXT.Pedalを抜いたときに、CN10 (on MB) の2番ピンが+5Vになりますか。

NG の場合:

IC8a、JK6 (on JB) とその周辺の素子及びパターンを チェックして下さい。また、D1、D2及びFL10 (on JB) を チェックして下さい。その他、EXT.Pedal自体の不良も考 えられます。

OK の場合:

R15、IC4、IC9、RA6、DA1、DA2、CA1 (on MB) とそれらの周辺パターンをチェックして下さい。また、IC5 (on MB) の 30 番ピンについて、ショートや足浮き・パターン切れがないかどうかチェックして下さい。異常がない場合は、IC5の不良も考えられます。

- b) HOLD Pedal が動作しない。
- ・ IC12 (on MB) の2番ピンにパルス波形が出ていますか。

NG の場合:

IC11 (on MB) について、ピン間のショートや足浮き・パターン切れをチェックして下さい。また、IC11またはIC12 自体の不良も考えられます。

HOLD Pedalを踏み込んだ時に、CN10 (on MB) の1番ピンが0Vになりますか。またHOLD Pedalを放した時に、CN10の1番ピンが+5Vになりますか。

NG の場合:

回路図を参照して、JK7からQ7 (on JB) に至るパターンと、そのパターンに接続されている素子をチェックして下さい。また、FL11 (on JB) をチェックして下さい。その他、JK7の接触不良やHOLD Pedal自体の不良も考えられます。

OK の場合:

IC11、IC12及びR29 (on MB) とそれらの周辺のパターンをチェックして下さい。

HOLD onの場合、Q7 (on JB) の3番ピンの電位はHigh レベル、IC12 (on MB) の1番ピンはLow レベルになり、IC12の3番ピンからはパルス波形が出力されます。

逆に、HOLD offの場合、Q7 (on JB) の3番ピンの電位はLow レベル、IC12 (on MB) の1番ピンはHigh レベル、IC12の3番ピンはHigh レベルになります。

10. LCD Malfunctions

Check the following items for all cases from a) to f).

- Check CN8, CN9 (on the MB) and the wirings which are connected to them.
- While referring to the circuit diagrams, check IC13 (on the MB) and its peripheral elements and patterns.
- a) Display is blank.
- Do all functions excepting the LCD work properly?

If not:

Main Board is not started up. Check the socket connection when the socket is used for ROM. Check the clock signals, the level of reset signals, address buss and data buss. Also check the chip select signals and interrupts of each IC.

If so:

The LCD itself may be defective. Also, RA15-RA17 (on the MB) may be defective.

- b) Display doesn't change.
- · Do all the functions excepting the LCD work properly?

If not:

It is possible that the program is runaway. Check the socket connection when the socket is used for ROM. Check the clock signals and the level of reset signals. Also check that there are no short circuits among the patterns or pattern cutoff.

If so:

The LCD itself may be defective. Also, RA15-RA17 (on the MB) may be defective.

- c) Display changes unexpectedly or contrary to panel control changes.
- It is likely that the slider, rather than the LCD, is defective. Refer to d) in "6. Slider is out of order."
- d) Backlight doesn't light.
- Is there voltage of +5V at pin number 1 on CN8 (on the MB)?

If not:

Check R30—R32, Q5, Q6 (on the MB) and their peripheral patterns.

If so:

It is possible that the backlight is burnt out.

- e) Screen is too dark or light.
- · Adjust the contrast by turning VR1 (on the MB).

When it cannot be adjusted:

Check that there is a voltage of 0.5 to 0.6V on pin number 1 of VR1. Also check that pin number 3 of VR1 is grounded. It is also possible that the LCD itself is defective.

LCD contrast is adjusted by the voltage on pin number 3 on CN9 (on the MB). The display is at optimum contrast when this voltage is 0.5 to 0.6V.

10. LCDがおかしい

以下、a)~f)の全ての場合において:

- ・ CN8及び CN9 (on MB) と、それらに接続されているワイヤリングをチェックして下さい。
- ・ 回路図を参照の上、IC13 (on MB) とその周辺の素子及びパターンをチェックして下さい。
- a) 表示が出ない。
- ・LCD以外の機能は正常ですか。

NGの場合:

メインボードが立ち上がっていません。ROMにソケットを使用している場合には、ソケットの接触をチェックして下さい。クロック信号及びリセット信号のレベル、アドレス・バス及びデータ・バス等をチェックして下さい。また、各ICへのチップ・セレクト信号及び割り込みもチェックして下さい。

OK の場合:

LCD の不良が考えられます。また、RA15~RA17 (on MB) の不良等も考えられます。

- b) 表示が変化しない。
- LCD以外の機能は正常ですか。

NG の場合:

プログラムが暴走している可能性があります。ROMにソケットを使用している場合には、ソケットの接触をチェックして下さい。クロック信号及クロック信号及びリセット信号のレベルをチェックして下さい。また、パターン間にショートやパターン切れがないかチェックして下さい。

OK の場合:

LCD の不良が考えられます。また、RA15~RA17 (on MB) の不良等も考えられます。

- c) 表示が勝手に変化する。
- LCDの不良よりはむしろ、スライダーの不良の可能性の方が 大きいです。「6.スライダーがおかしい」のd)を参照して下さい。
- d) バックライトが光らない。
- CN8 (on MB) の1番ピンに+5Vの電圧が出ていますか。

NG の場合:

R30~R32、Q5及びQ6 (on MB) とそれらの周辺のパター ンをチェックして下さい。

OK の場合 :

バックライトが切れている可能性があります。

- e) 画面が濃い(もしくは薄い)。
- VR1 (on MB) を回し、適当な濃さになるよう調整して下さい。

調整できない場合:

VR1の1番ピンに $0.5\sim0.6$ V程度の電圧がかかっているかどうかチェックして下さい。また、VR1の3番ピンがGNDに接続されていることを確認して下さい。その他、LCDの不良等の可能性もあります。

LCDのコントラストは、CN9 (on MB) の3番ピンにかかる電圧によって調整されています。この電圧が $0.5\sim0.6$ Vの時に、最も表示が見やすくなります。

- f) Characters are incorrect.
- Check CN9 (on the MB) and the wirings connected to it. Check IC13, RA15—RA17 (on the MB) and their peripheral patterns.
- Occasionally (but seldom) the displayed characters can be corrupted by static electricity.

f)文字がおかしい。

- ・CN9 (on MB) 及びそこに接続されているワイヤリングを チェックして下さい。また、IC13、RA15~RA17 (on MB) 及 びそれらの周辺パターンをチェックして下さい。
- ・まれに、静電気によって文字がおかしくなる場合があります。

[3] Problems in the sound

Check the following items in all cases 1-8, below.

- Check the connection between CN10 (on the MB) and CN5 (on the JB).
- Check the connection between CN1 (on the JB) and CN2 (on the BB).

1. No sound or sound is distorted

 Referring to a) in [5] "1. Keyboard Malfunctions," check the operation of the keys.

When it's inoperative:

Check the connection between CN7 (on the MB) and the keys. Also check IC11 (on the MB) and its peripherals.

 Is the PCM ROM in working order? (Refer to [3] in the TEST MODE section, p.30.)

If not:

Check IC24, IC25, IC26 (on the MB) and their peripherals. Especially check that there is no short circuit or loose pin between the pins on IC24. Also check the busses connected to IC24, IC25 and to IC26. Since the buss is connected to the card board, check it after disconnecting the wiring. Also check the same thing for IC1 (on the CB). It is possible that IC24, IC25 or IC26 themselves are defective.

HOW TO FIND SHORT CIRCUITS AMONG THE BUSSES Observe the pulse waveform on the busses by oscilloscope. The minimum voltage of the waveform is OV and the maximum is +5V when it is operating properly. On the other hand, when the buss is short-circuiting with another buss next to it, the maximum voltage of the pulse wave doesn't reach near +5V, but comes to a point somewhere between OV and +5V.

 Is a high frequency pulse waveform output from pin numbers 69—90 on IC24 (on the MB) and 94 when a key is pressed?

If not:

The operation of IC24 may be defective. Check that there is no short circuit or pattern cutoff for patterns which are connected to IC24. Also check that a clock signal of sufficient level is supplied to IC24. Also check that there are no abnormalities of the reset signals and buss signals. It is also possible that IC24 itself is defective.

【3】音に関する不良

以下、1~8の全ての場合において:

- ・CN10 (on MB) とCN5 (on JB) の間の接続をチェックして 下さい。
- CN1 (on JB) とCN2 (on BB) の間の接続をチェックして下さい。

1.音が出ない・音がひずむ

•【5】の「1.鍵盤の不良」のa)を参照して、鍵盤の動作をチェックして下さい。

NGの場合:

CN7 (on MB) と鍵盤の間の接続をチェックして下さい。 また、IC11 (on MB) 及びその周辺をチェックして下さい。

PCM ROMは正常ですか。(テストモードの【3】(P.30)を参照して下さい。)

NGの場合:

IC24、IC25及びIC26 (on MB) とその周辺をチェックして下さい。特に、IC24のピン間のショートや足浮きがないかチェックして下さい。IC24からIC25及びIC26に接続されているバスについてもチェックして下さい。バスはカードボードにも接続されていますので、一旦ワイヤリングを抜いた上でチェックを行って下さい。また、IC1 (on CB)についても同様にチェックして下さい。その他、IC24、IC25またはIC26自体の不良が原因の場合もあります。

バス間のショートの発見方法

バスに乗っているパルス波形をオシロスコープで観測して下さい。正常な状態では波形の最小電圧は 0V で、最大電圧は約+5Vになっています。一方、バスが隣のバスとショートした状態では、パルス波形の最大電圧は+5V近くまで上がり切らず、0Vと+5Vの間の中途半端な電圧が現れます。

・鍵盤を弾いた時に、IC24 (on MB) の69~90及び94番ピン に高い周波数のパルス波形が出力されますか。

NG の場合:

IC24の動作不良が考えられます。IC24に接続されているパターンにショートやパターン切れがないかチェックして下さい。また、IC24に十分なレベルのクロックが供給されているかチェックして下さい。リセット信号やバスの信号に異常がないかもチェックして下さい。IC24自体の不良も考えられます。

 Is a high frequency pulse waveform output from pin numbers 63—82 on IC23 (on the MB) and 88 when a key is pressed?

If not:

The operation of IC23 may be defective. Check that there is no short circuit or pattern cutoff for patterns which are connected to IC23. Also check that a synchronizing signal of sufficient level is supplied to pin number 23 and 24 on IC23. Also check that there are no abnormalities of the reset signals and buss signals. It is also possible that IC23 itself is defective.

 Is serial data of voice output on pin number 4 on CN10 (on the MB) when key is pressed?

If not:

Check FL5 (on the MB). When there is no abnormality with FL5, operation of IC22 (on the MB) may be defective. Check that there is no short circuit or pattern cutoff of patterns connected to IC22. Also check that a clock signal of sufficient level is supplied to pin number 62 on IC22. Check that there are no abnormalities with the reset signals and buss signals. It is also possible that IC22 itself is defective.

 Is a high frequency pulse waveform output from pin numbers 5—10 on CN10 (on the MB)?

If not:

First check FL6—FL11, R33—R36 and C101 (on the MB). If no abnormalities are found, the operation of IC22 (on the MB) may be defective. Check that there is no short circuit or pattern cutoff of patterns which are connected to IC22. Also check that a clock signal of sufficient level is supplied to pin number 62 on IC22. Check that there are no abnormalities with reset signals and buss signals. It is also possible that IC22 itself is defective.

Serial data of voice and pulse signals for demultiplex are sent to the jack board after passing through FL5—FL11 on the Main Board. When the timing of data becomes incorrect due to an error or defect in the characteristics of FL5—FL11, noise or distortion in the sound will result. In the worst case, no sound will be output.

 Is a voice waveform of small amplitude output from pin number 1 on IC12 (on the JB) when a key is pressed?

If not:

The operation of IC11 or IC12 (on the JB) may be defective. Check IC11 and IC12, and their peripherals. If no abnormality is found, IC11 or IC12 may themselves be defective.

・鍵盤を弾いた時に、IC23 (on MB) の63~82 及び88 番ピン に高い周波数のパルス波形が出力されますか。

NGの場合:

IC23の動作不良が考えられます。IC23に接続されているパターンにショートやパターン切れがないかチェックして下さい。また、IC23の21及び24番ピンに、十分なレベルの同期信号が供給されているかチェックして下さい。リセット信号やバスの信号に異常がないかもチェックして下さい。IC23自体の不良も考えられます。

・ 鍵盤を弾いた時に、CN10 (on MB) の4番ピンに音声のシリアルデータが出力されますか。

NGの場合:

FL5 (on MB) をチェックして下さい。FL5に異常がない場合は、IC22 (on MB) の動作不良が考えられます。IC22 に接続されているパターンにショートやパターン切れがないかチェックして下さい。また、IC22の62番ピンに、十分なレベルのクロックが供給されているかチェックして下さい。リセット信号やバスの信号に異常がないかもチェックして下さい。IC22自体の不良も考えられます。

• CN10 (on MB) の5~10番ピンに、高い周波数のパルス波形 が出力されていますか。

NG の場合:

まずFL6~FL11、R33~R36及びC101 (on MB) をチェックして下さい。異常がない場合は、IC22 (on MB) の動作不良が考えられます。IC22 に接続されているパターンにショートやパターン切れがないかチェックして下さい。また、IC22の62番ピンに、十分なレベルのクロックが供給されているかチェックして下さい。リセット信号やバスの信号に異常がないかもチェックして下さい。IC22自体の不良も考えられます。

音声のシリアルデータやデマルチプレクス用のパルス信号は、メインボード上でFL5~FL11を通った後、ジャックボードに送り出されています。FL5~FL11の特性の誤差や不良等によってデータのタイミングが狂ったり、レベルが低下したりすると、結果として音にノイズが乗ったり、音がひずんだりします。最悪の場合、音が出なくなることもあります。

・ 鍵盤を弾いた時に、IC12 (on JB) の1番ピンから、振幅の小 さな音声波形が出力されますか。

NG の場合:

IC11 または IC12 (on JB) の動作不良が考えられます。 IC11及びIC12と、それらの周辺をチェックして下さい。異常がなければ、IC11 または IC12 自体の不良が考えられます。

 Is a voice waveform output from pin number 1, 12, 14 and 15 on IC13 when a key is pressed?

If not:

Check that the pulse signals for demultiplex are input in pin numbers 6 and 9—11 on IC13 (on the JB). Also check that the voice waveform from the pin number 1 on IC12 (on the JB) is input in pin number 3 on IC13. If no abnormality is found, IC13 itself may be defective.

 Disconnect the wiring which is connected to CN1 (on the JB) and connect pin numbers 2 and 6, and 3 and 5 on CN1 making a short circuit by jumper line and check that sound is output when a key is pressed.

When sound is output:

VR1 or CN2 (on the BB) may be defective. The wiring may also be defective.

 Is the voltage of pin number 3 of Q1—Q6 (on the JB) less than OV (negative voltage)?

When it's not less than OV:

The mute circuit is on. Check Q1—Q6, Q10, Q12—Q14 (on the JB) and their peripheral patterns and elements, referring to the circuit diagrams.

 Referring to the circuit diagrams, check the elements and patterns of the circuits from IC13 to JK1—JK5 (on the JB).

2. Sound doesn't stop.

- The HOLD Pedal might be left on. Check while referring to [2] 9. b) "HOLD Pedal doesn't function".
- It is possible that data from the keyboard cannot be read because of defects in IC11 and IC13 (on the MB). Check the reading of the keys, referring to [5] "1. Keyboard Malfunctions".

3. Noise elements in the sound.

- a) Noise only occurs along with the sound.
- Adjust the D/A converter, referring to [15] in the TEST MODE section, p.32.
- There is a possibility that the sound source operation is defective. Check IC21—IC26 (on the MB) and their peripherals, referring to [3] "1. No sound, or sound is distorted". Also check IC1 (on the CB) and its
- It is possible that the sound with distortion sounds like noise, because of an error and defect of characteristics in FL5—FL11 (on the MB). Refer to [3] "1. No sound, or sound is distorted".
- It is possible that effect operation is defective. Check, while referring to [3] "4. Effect Malfunctions".
- b) Pulse-like noise sounds intermittently.
- This kind of problem can be caused when the level and timing of serial data become incorrect because of an error or defect of the characteristics of FL5—FL7 (on the MB). Check FL5—FL7 and their peripherals.

鍵盤を弾いた時に、IC13 (on JB) の1、12、14及び15番ピンから音声波形が出力されますか。

NG の場合:

IC13 (on JB) 06及び $9\sim11$ 番ピンにデマルチプレクス用のパルス信号が入力されているかどうかチェックして下さい。また、IC13の3番ピンに、IC12 (on JB) 01番ピンからの音声波形が入力されているかどうかチェックして下さい。異常がなければIC13自体の不良が考えられます。

• CN1 (on JB) に接続されているワイヤリングを抜き、CN1 の 2番ピンと6番ピン、3番ピンと5番ピンをそれぞれジャンパー 線等で短絡し、鍵盤を弾いた時に音が出るかどうかチェックして下さい。

音が出る場合:

VR1またはCN2 (on BB) の不良が考えられます。また、ワイヤリングの不良も考えられます。

 Q1~Q6 (on JB) の3番ピンの電圧が0V以下(マイナス電圧) になっていますか。

0V以下でない場合:

ミュート回路が働いています。回路図を参照して、Q1~Q6、Q10及びQ12~Q14 (on JB) とそれらの周辺のパターン及び素子をチェックして下さい。

 回路図を参照して、IC13からJK1~JK5 (on JB) に至るまで の素子及びパターンをチェックして下さい。

2. 音が止まらない

- HOLD Pedalがonになりっ放しになっていると考えられます。
 【2】の9.のb)「HOLD Pedalが動作しない」を参照してチェックを行って下さい。
- IC11及びIC13 (on MB) の動作不良により、鍵盤を読み込めなくなった可能性が考えられます。

【5】の1.「鍵盤の不良」を参照して、鍵盤の読み込みのチェックを行って下さい。

3.音にノイズが乗る

- a) 音が鳴っている間だけノイズが乗る。
- まずテストモードの【15】(P.32)を参照して、D/A調整を行って下さい。
- ・ 音源の動作不良の可能性もあります。

【3】の1.「音が出ない・音がひずむ」を参考にしながら、IC21 ~IC26 (on MB) とそれらの周辺のチェックを行って下さい。また、IC1 (on CB) とその周辺のチェックを行って下さい。

• FL5~FL11 (on MB) の不良や特性の誤差によっては、音が ひずみ、ノイズのように聞こえる場合があります。 【3】の1.「音が出ない・音がひずむ」を参照して下さい。

・エフェクトの動作不良の可能性もあります。【3】の4.「エフェクトがおかしい」を参照してチェックを行って下さい。

b) 断続的にパルス状のノイズが出る。

FL5~FL7 (on MB) の不良や特性の誤差によって、シリアルデータのレベルやタイミングが狂うと、このような症状が出ることがあります。FL5~FL7とそれらの周辺をチェックして下さい。

4. Effect malfunctions.

- Check that a clock signal of sufficient level is supplied to pin number 2 on IC21 (on the MB). Check the level of the reset signal which is input to pin number 94 on IC21. Also check the serial data on pins numbered 7—10 on IC21.
- Check IC14—IC19 (on the MB) and their peripherals.
 Also check the signals which are supplied from pins numbered 59, 64 and 66 on IC21 (on the MB).
- · Check IC22 (on the MB) and its peripherals.

5. Sound volume is low

- There may be a decrease of gain in the analog output circuits. Check the analog output circuits on the Jack Board, referring to the circuit diagrams. Also check VR1 (on the BB).
- It is possible that the volume becomes low because the EXT. Pedal is out of order. Refer to a) and b) in [2] "9. Pedal Malfunctions".

6. Scale or tuning is incorrect

- Check the frequency of the clock which is supplied to pin number 24 on IC24 (on the MB). The correct frequency is 26.195MHz.
- Check the frequency of the clock which is supplied to pin number 62 on IC22 (on the MB). The correct frequency is 28.224MHz.
- It is possible that the pitch is effected by the defect of bender, modulation, after touch or EXT. Pedal. Check while referring to [2] "8. Malfunctions of the Bender, Modulation, and After Touch" and "9. Pedal Malfunctions".

7. There is a lot of noise even when the instrument should be silent

- Check the constant of IC5, IC7, IC11—IC13, C30, C35, C38 and C43 (on the JB). Also check the analog output circuits on the Jack Board by referring to the circuit diagrams.
- The S/N ratio could worsen due to a ripple in the \pm 15V power supply. Check the voltage and power consumption of the \pm 15V power supply. The rated current of \pm 15V is 500mA and when the current becomes greater than that, ripples are casued. In such a case, check the \pm 15V power source pattern and all the elements which are connected to them.

8. The stereo output doesn't function properly, or the balance of the right and left signals is incorrect.

 Is the serial data correctly output at pin number 4 on CN10 (on the MB) when a key is pressed?

If not:

The sound source circuit may be defective. Check the sound source circuit and its peripherals by referring to [3] "1. No sound, or sound is distorted".

4.エフェクトがおかしい

- ・IC21 (on MB) の2番ピンに十分なレベルのクロックが供給されているかチェックして下さい。IC21の94番ピンに入力されているリセット信号のレベルをチェックして下さい。また、IC21の7~10番ピンのシリアルデータをチェックして下さい。
- IC14~IC19 (on MB) とそれらの周辺をチェックして下さい。 また、IC21 (on MB) の59、64、66番ピンから供給される信 号をチェックして下さい。
- ・IC22 (on MB) とその周辺をチェックして下さい。

5. 音量が小さい

- ・アナログ出力系の回路におけるゲインの低下が考えられます。 回路図を参照して、ジャックボード上のアナログ出力系の回路 をチェックして下さい。また、VR1 (on BB) をチェックして 下さい。
- ・ EXT.Pedalの不良により、Volume レベルが小さくなっている 可能性もあります。
- 【2】の9.「ペダル類の不良」のa)及びb)を参照して下さい。

6. 音程がおかしい

- IC24 (on MB) の24番ピンに供給されているクロックの周波数をチェックして下さい。
 周波数は26,195MHzです。
- ・IC22 (on MB) の62番ピンに供給されているクロックの周波数をチェックして下さい。
- 周波数は28.224MHzです。
- ・ベンダー・モジュレーション・アフタータッチまたはEXT. Pedal 等の不良により、ピッチに影響が出ている場合があります。
- 【2】の8.「ベンダー・モジュレーション・アフタータッチの不良」及び9.「ペダル類の不良」を参照してチェックして下さい。

7.無音時のノイズが多い

- IC5、IC7、IC11~IC13、C30、C35、C38及びC43 (on JB) の 定数をチェックして下さい。また、回路図を参照して、ジャッ クボード上のアナログ出力系の回路をチェックして下さい。
- ・ \pm 15V 電源にリプルが乗って S/N 比を悪化させている場合があります。 \pm 15V 電源の電圧と消費電流をチェックして下さい。なお、 \pm 15V 電源の定格電流は500mA ですので、それより大きな電流が流れるとリプルが乗ります。その場合には、 \pm 15V 電源パターン及びそこに接続されている全ての素子をチェックして下さい。

8. ステレオにならない・左右の音量バランスがおかしい。

・鍵盤を弾いた時に、CN10 (on MB) の4番ピンに、シリアル データが正常に出力されますか。

NGの場合:

音源回路の動作不良が考えられます。

【3】の1.「音が出ない・音がひずむ」を参考にして、音源回路とその周辺のチェックを行って下さい。

 Is the voice waveform output at pins numbered 1 and 12 on IC13 (on the JB) when a key is pressed?

If not:

Check IC11—IC13 (on the JB) and their peripherals. Especially check the signal waveform for demultiplex which is input to pins numbered 9—11 on IC13.

 Check the analog output circuits on the Jack Board by referring to the circuit diagrams. Also check VR1 (on the BB). Check the connection between bender board and the jack board, as well.

[4] MIDI Malfunctions

1.MIDI signals are not output

• Does the instrument sound when keys are pressed?

When it doesn't:

There is a possibility that the keys are not being read correctly. Check the operation of the keys by referring to [5] "1. Keyboard Malfunctions".

 Observe pin number 1 on CN15 (on the MB) and pin number 4 on IC10 (on the JB) with an oscilloscope, and check that active sensing is output.

When it's not output through CN15:

Check the patterns between CN15 and IC36 on the Main Board. Also check R53. If nothing wrong is found, the operation of IC36 may be defective.

When it's output through CN15 but not IC10:

Check the connection between CN15 (on the MB) an CN5 (on the JB). Check the patterns from CN6 (on the JB) to IC10 (on the JB), as well as L6 and L7 (on the JB), referring to the circuit diagrams. Check also Q8, Q11, R47, R48, R51 and L12—L14 (on the JB) and their peripherals. If nothing wrong is found, the operation of IC10 may be defective.

2. MIDI signals are not received.

· Does it sound when keys are pressed?

When it doesn't:

There is a possibility that the keys are not being read correctly. Check the operation of the keys by referring to [5] "1. Keyboard Malfunctions".

 Using an oscilloscope, observe the waveform at pin number 2 on IC9 (on the JB), pin 6 of IC9 (on the JB) and pin 3 on CN15 (on the MB) when MIDI is input.

When there is no pulse at any points:

Check L10, L11, R44, R45 and D5 (on the JB).

・鍵盤を弾いた時に、IC13 (on JB) の1番ピンと12番ピンに音 声波形が出力されますか。

NGの場合:

IC11~IC13 (on JB) とそれらの周辺のチェックを行って下さい。特に、IC13の9~11番ピンに入力されているデマルチプレクス用の信号波形をチェックして下さい。

回路図を参照して、ジャックボード上のアナログ出力系の回路をチェックして下さい。また、VR1 (on BB) をチェックして下さい。ベンダーボードとジャックボード間の接続についてもチェックを行って下さい。

【4】MIDIの不良

1.MIDI信号が出力されない

・ 鍵盤を弾いた際に音は出ますか。

出ない場合:

鍵盤の読み込みが正常に行われていない可能性があり ます。

【5】の1.「鍵盤の不良」を参照して、鍵盤の動作チェックを 行って下さい。

• CN15 (on MB) の1番ピン及びIC10 (on JB) の4番ピンを オシロスコープで観測し、アクティブ・センシングが出力され ているかチェックして下さい。

CN15に出ていない場合:

メインボード上のCN15とIC36の間のパターンをチェックして下さい。また、R53をチェックして下さい。異常がない場合はIC36の動作不良が考えられます。

CN15に出ていてIC10に出ていない場合:

CN15 (on MB) と CN6 (on JB) の間の接続をチェックして下さい。回路図を参照して、CN6 (on JB) からIC10 (on JB) に至るパターン及びL6、L7 (on JB) をチェックして下さい。また、Q8、Q11、R47、R48、R51及びL12~L14 (on JB) とそれらの周辺をチェックして下さい。異常がない場合はIC10の不良が考えられます。

2.MIDI信号を受信しない

・鍵盤を弾いた際に音が出ますか。

出ない場合:

鍵盤の読み込みが正常に行われていない可能性があり ます。

【5】の1.「鍵盤の不良」のa)を参照して、鍵盤の動作 チェックを行って下さい。

IC9 (on JB) の2番ピン、IC9 (on JB) の6番ピン及びCN1
 5 (on MB) の3番ピンの各ピンについて、MIDIが入力された際の波形をオシロスコープで観測して下さい。

どのポイントにもパルスが現れない場合:

L10、L11、R44、R45及びD5 (on JB) をチェックして下さい。

When pulse appears only at pin number 2 of IC9:

Check R46, IC9, IC10, L6, CN6 (on the JB) and their peripherals. Especially chack that there is no short circuit in the patterns. If there is no bad connection between CN6 (on the JB) and CN15 (on the MB), IC9 (on the JB) may be defective.

Since a similar problem is caused when there is a short circuit in the peripheral patterns of CN15, check the same thing with the wirings being disconnected from CN15.

When a pulse appears at pin number 2 and pin number 6 on IC9:

Check L6 (on the JB). Check also the connection between CN6 (on the JB) and CN15 (on the MB).

When a pulse appears at all the pins:

Check that there are no loose pins or pattern cutoff of IC36 (on the MB). If everything is normal, IC36 may be defective.

[5] Other Malfunctions

1. Keyboard Malfunctions

- a) Sound isn't output when keys are pressed.
- Make a thorough test of the keyboard, referring to [11] in the TEST MODE section, p.32.

When there are no sounding keys within an octave:

The scan line of the keyboard matrix may be defective. Check that there is pulse waveform at pins numbered 8—16, 63—68, 70—75 and 77—80 on IC11 on the Main Board. Check the cable which connects the Main Board to the keys as well. It is also possible that the flexible plate on the keys is defective.

When sound isn't output from any of the keys:

There is a possibility that the keys are not being read correctly. Check IC11 and its peripherals on the Main Board. Also check the cable connection from the keys to CN7 on the Main Board. The keys themselves may also be defective.

Observe pin number 26 on IC11 by oscilloscope in order to find out whether keys are read in by IC11 or not. When the keys are not pressed, High level is output, but when a key is pressed, a pulse is output at Low level for a second. This is because IC11 reads the keys and as a result it interrupts the CPU. Confirming this makes it almost certain that the keys are being read correctly. If you want to make absolutely sure of this, observe pin number 77 on IC36. All the interruptions from all the ICs on the Main Board are unified by IC13 and are input in pin number 77 of IC36 which is the CPU. In this way many pulses can be observed, so find the pulses which appear only when the keys are hitted.

IC9の2番ピンにのみパルスが現れる場合:

R46、IC9、IC10、L6、CN6 (on JB) とその周辺をチェックして下さい。特に、パターンのショートがないかチェックして下さい。また、CN6 (on JB) とCN15 (on MB) の接異常がない場合はIC9 (on JB) の不良が考えられます。なお、CN15 (on MB) 周辺のパターンがショートしていると同様の症状が現れますので、CN15からワイヤリングを抜いた状態で同様にチェックを行って下さい。

IC9の2番ピン及び6番ピンにパルスが現れる場合:

L6 (on JB) をチェックして下さい。また、CN6 (on JB) とCN15 (on MB) の間の接続をチェックして下さい。

全てにパルスが現れる場合:

IC36 (on MB) の足浮きやパターン切れをチェックして下さい。異常がない場合はIC36の不良が考えられます。

【5】その他の不良

1.鍵盤の不良

- a) 鍵盤を弾いても音が出ない。
- ・テストモードの【11】(P.32)を参照して、鍵盤のチェックを 一通り行って下さい。

8音単位で音の出ない鍵盤がある場合:

キーボード・マトリクスのスキャン線に異常があると考えられます。回路図を参照して、メインボード上IC11の8~16番ピン、63~68番ピン、70~75番ピン及び77~80番ピンにパルス波形が出ることをチェックして下さい。また、メインボードと鍵盤を接続しているケーブルをチェックして下さい。鍵盤上のフレキシブル基板の不良も考えられます。

全ての鍵盤で音が出ない場合:

鍵盤の読み込みの不良が考えられます。メインボード上の IC11とその周辺をチェックして下さい。また、メインボード上の CN7から鍵盤に至るケーブルの接続をチェックして下さい。鍵盤自体の不良も考えられます。

鍵盤がIC11によって読み込まれているかどうかを知るには、IC11の26番ピンをオシロスコープで観測して下さい。鍵盤を弾いていない時にはHighレベルが出力されていますが、鍵盤を弾くと、ほんの一瞬Lowレベルのパルスが出力されます。これはIC11が鍵盤を読み込んだ結果、CPUに対して割り込みをかけたのです。

これが確認されれば、鍵盤は正常に読み込まれていると思ってまず間違いありません。もし正確を期したい場合には、IC36の77番ピンを観測して下さい。メインボード上の全てのICからの割り込みは、IC13によって一括され、CPUであるIC36の77番ピンに入力されています。このため、多数のパルスが観測されると思いますが、鍵盤を弾いた瞬間だけに現れるパルスを見つけ出して下さい。

- Keys make a clicking or scraping sound when they are pressed.
- The plate springs of the keys are loose, or not enough lubrication has been applied to the plate spring. Repair them by referring to "How to remove the keys" and "How to replace the keys" (p.7).

When lubrication is needed, specify "Froil G474-B" in the order form and send it to the service center.

- c) The action of the keyboard is exceptionally hard
- The plate springs of the keys are not installed correctly.
 Repair them by referring to "How to remove the keys" and "How to replace the keys" (p. 7).
- d) Keys come off
- The stoppers of the keys are loose. Repair them by referring to "How to remove the keys" and "How to replace the keys" (p.7).

2. The buttons and switches are hard to operate

 Switches, sliders or volumes may be tilted or at an angle in the plate and are touching the holes. Check them by referring to the exploded view.

b) 鍵盤を弾くとカチカチと音が出る

・鍵盤の板バネが外れかかっているか、もしくは板バネのグリースが不足している可能性があります。「キーの取り外し方」及び「キーの取り付け方」(P.7)を参照して修理して下さい。

グリースを要求する場合は、「フロイルG474-B」とオーダーシートに書いてサービスセンターに要求して下さい。

c) 鍵盤が固い

・鍵盤の板バネがきちんと取り付けられていないことが原因と 考えられます。「キーの取り外し方」及び「キーの取り付け方」 (P.7)を参照して修理して下さい。

d) 鍵盤がはずれる

・鍵盤のストッパーが外れかかっていることが考えられます。 「キーの取り外し方」及び「キーの取り付け方」(P.7)を参照して修理して下さい。

2.つまみ・スイッチ類が固い


・スイッチ、スライダーまたはボリュームが、基板に傾いて取り 付けられているために取り付け穴に接触していることが考えら れます。分解図を参照してチェックして下さい。

IC DATA/ICデータ

MB → Main Board VLB → Volume_L Board PSB → Power Supply Board JB → Jack Board VRB → Volume_R Board CB → Card Board

Sub CPU (IC5 on MB)

Main CPU (IC36 on MB) H8/532 (15199765)




PIN NO.	NAME	PIN NO.	NAME	PIN NO.	NAME
1	R/W	28	A7	55	AN3
2	DS	29	VSS	56	AN4
3	RD	30	AB	57	AN5
4	WR	31	A9	58	AN6
5	VCC	32	A10	59	AN7
6	MDO	33	A11	60	AVCC
7	MD1	34	A12	61	P.9-0
8	MD2	35	A13	62	P.9-1
9	STBY	36	A14	63	PW1
10	RES	37	A15	64	PW2
11	NMI	38	A16	65	PW3
12	VSS	39	A17	66	TxD
13	DO	40	A18	67	RxD
14	D1	41	A19	68	SCK
15	D2	42	VCC	69	EXTAL
16	D3	43	P.7-0	70	XTAL
17	D4	44	P.7-1	71	VSS
18	D5	45	P.7-2	72	PHAI
19	D6	46	P.7-3	73	Ε
20	D7	47	P.7-4	74	BACK
21	AO	48	P.7-5	75	BREQ
22	A1	49	P.7-6	76	WAIT
23	A2	50	P.7-7	77	IRQO
24	A3	51	AVSS	78	IRQ1
25	A4	52	ANO	79	TMO
26	A5	53	AN1	80	ĀS
27	A6	54	AN2		
<u></u> /		1 54	ni14		L

H8/330 (15199742)


				r	1
PIN NO.	NAME	PIN NO.	NAME	PIN NO.	NAME
1	RES	28	P.6-7	55	P.2-0
2	XTAL	29	AVCC	56	VSS
3	EXTAL	30	ANO	57	P.1-7
4	MD1	31	AN1	58	P.1-6
- 5	MDO	32	AN2	59	P.1-5
6	NMI	33	ENA	60	P.1-4
7	STBY	34	AN4	61	P.1-3
- 8	VCC	35	AN5	62	P.1-2
9	P.5-2	36	AN6	63	P.1-1
10	P.5-1	37	AN7	64	P.1-0
11	P.5-0	38	AVSS	65	DO
12	VSS	39	P.4-0	66	D1
13	P.9-7	40	P.4-1	67	D2
14	P.9-6	41	P.4-2	68	D3
15	RDY	42	P.4-3	69	D4
16	ŌĒ	43	P.4-4	70	D5
17	ĊŚ	44	P.4-5	71	D6
18	IRQO	45	P.4-6	72	D7
19	IRQ1	46	P.4-7	73	VSS
20	IRQ2	47	VCC	74	P.8-0
21	P.6-0	48	P.2-7	75	P.8-1
22	P.6-1	49	P.2-6	76	P.8-2
23	P.6-2	50	P.2-5	77	P.8-3
24	P.6-3	51	P.2-4	78	P.8-4

TOP VIEW


PCM Custom Chip (IC24 on MB) MB87731A (15239168)




TVF Chip (IC23 on MB) MB87424A (15239169)



IC DATA/ICデータ







Analog Multiplexer

[SOP]
BU4051BF T-2 (IC4 on MB) (15259101) [DIP]
TC74HC4051 (IC13 on JB)
(15169596)
BU4051B (IC4-6 on VLB, IC4-7 on VRB)
(15159113D0)

_ NOTE : Each "4051" is electrically incompatible with the others.
Replacement must be only the "4051" specified on the circuit diagram.

	Г	~~	\neg	
4	1		16	VCC
6	2		15	2
COM	3		14	1
7	4		13	0
5	5		12	3
INH	6		11	A
VEE	7		10	В
GND	8		9	C
	L			
	TC	IP VT	F₩	

CONTROL	ΙN	bΩ,	rs	"ON"
INHIBIT	C	В	Α	CHANNEL
L	L	L	L	0
L.	L	L	Н	1
L	L	Н	L	. 2
L	L	Н	Н	3
L	H	L	L	4 5 6
L	Н	L	Н	5
L	Н	Н	L	6
L	Н	Н	Н	7
Н	X	X	Χ	NONE
X: DON'T (A	RF.		

Reset IC (IC1 on PSB) M51953AL (15219183)

